

AWARNING

Improper vehicle use can result in SEVERE INJURY or DEATH

NEVER Operate:

- Without first viewing owner's manual and quick start guide.
- •With more than one passenger.
- This vehicle is not only applicable for public roads, but also field road.
- •With Non-CFMOTO approved accessories.

ALWAYS:

- Keep hands and feet inside vehicle.
- Reduce speed and use extra caution when carrying a passenger.
- Operate slowly in reverse-avoid sharp turns or sudden braking.
- Make sure passenger reads and understands all safety labels.
- Watch for branches or other hazards that could enter vehicle.
- •Use safety belt during operation.



ALWAYS USE AN APPROVED HELMET AND PROTECTIVE GEAR



Locate and Read Owner's manual, Follow all INSTRUCTIONS and WARNINGS. If Owner's manual is missing, contact a CFMOTO dealer for replacement.

AWARNING

Read, understand, and follow all of the instructions and safety precautions in this manual and on all product labels. Failure to follow the safety precautions could resullt in serious injury or death.

AWARNING

The engine exhaust gas from this product contains CO, which is deadly gas and could cause headache, giddy, disgusting or lose consciousness, even death.

AWARNING

Engine box cover, brake disc and muffler exhaust pipe will be hot easily after long period usage. Avoid being burned by those parts.

INSTRUCTIONS

Thank you for purchasing a CFMOTO vehicle, and welcome to join our worldwide family of CFMOTO owners.

We proudly produce an exciting line of utility and recreational products.

- All terrain vehicle (ATV)
- Utility vehicle (patrol, forest protecting and hunting)
- Motorcycles and scooters
- Tractor

CFMOTO, a company which is specialized in production of liquid-cooled engine, is the top-level supplier in China. Compared to same displacement of air-cooled engine, engine cooling effect is better, oil temperature can be adjusted more freely, more powerful and lower fuel consumption, longer engine working life.

For safe and enjoyable operation of your vehicle, be sure to follow the instructions and recommendations in this owner's manual. Your manual contains instructions for minor maintenance, but information about major repairs is outlined in the CFMOTO service manual and should be performed only by CFMOTO service dealer and technician.

Your CFMOTO dealer knows your vehicle best and is interested in your total satisfaction. Be sure to return to your dealership for all of your service.


Due to constant improvements in the design and quality of production components, some minor discrepancies may result between the actual vehicle and the information presented in this publication. Depictions and/or procedures in this publication are intended for reference use only.

TABLE OF CONTENTS

VIN No·····	٠5
Operator Safety·····	· 6
Safety decals and locations	43
Features and Controls	49
Operation ····································	69
Maintenance & Lubrication	
Clean & Storage	142
Troubleshooting 1	148
Specifications 1	159
Declaration of Drivers exposure to noise level	167
Declaration of Vibration declaration	
LIMITED WARRANTY 1	1 69

VEHICLE IDENTIFICATION NUMBER

Record your Tractor's identification numbers in the spaces provided, Remove the spare key and store in a safe place. Your key can be duplicated only by mating key blank with one of your existing keys. So if both keys are lost, the complete lock kits have to be replaced.



- (1) CF400ATR-2S /CF500ATR-2S Vehicle identification number:
- (2) CF400ATR-2L/CF500ATR-2L Vehicle identification number: ______
- ③ Vehicle model number: _____

AWARNING

Failure to heed the warnings contained in this manual can result in serious injury or death. An Tractor is not a toy and can be hazardous to operate. This vehicle handles differently from other vehicles, such as motorcycles and cars. A collision or rollover can occur quickly, even during routine manneuvers, like turning, or over obstacles, if you fail to take proper precautions.

Read this owner's manual. Understand all safety warnings, precautions and operating procedures before operating an Tractor.

Age Restrictions

This vehicle is an ADULT VEHICLE ONLY. Operation is prohibited for anyone under the age of 16.

Know Your Vehicle

As the operator of the vehicle, you are responsible for your personal safety, the safety of others, and the protection of our environment. Read and understand your owner's manual, which includes valuable information about all aspects of your vehicle, including safe operating procedures.

Familiarize yourself with all laws and regulations concerning the operation of this vehicle in your area. We strongly advise you to strictly follow the recommended maintenance program outlined in your owner's manual. This preventive maintenance program is designed to ensure that all critical components on your vehicle are thoroughly inspected at specific intervals. The following signal words and symbols appear throughout this manual and on your Tractor. Your safety is involved when these words and symbols are used. Become familiar with their meanings before reading the manual.

AWARNING

The safety alert warning indicates a potential hazard that may result in serious injury or death.

CAUTION

The safety alert caution indicates a potential hazard that may result in minor personal injury or damage to the vehicle.

NOTE

A note will alert you to important information or instructions.

• Read this manual and all labels carefully, and follow the operating procedures described.

- Never operate an Tractor without proper instruction.
- Never allow anyone under 16 years of age to operate this Tractor.
- Never permit a guest to operate the Tractor unless the guest has read this manual and all product labels and has completed a certified safety training course.
- Never operate an Tractor without wearing an approved helmet that fits properly. Always wear eye protection (goggles or face shield), gloves, boots, a long-sleeved shirt or jacket, and long pants.
- Never consume alcohol or drugs before or while operating an Tractor.
- Never operate at excessive speeds. Travel at speeds appropriate for the terrain, visibility and operating conditions, and your experience.
- Never attempt wheelies, jumps or other stunts.
- Always inspect your Tractor before each use to make sure it's in safe operating condition. Always follow the inspection and maintenance procedures and schedules outlined in your owner's manual.

- Always keep both hands on the handlebars and both feet on the foot-rests of the Tractor during operation.
- Always travel slowly and use extra caution when operating on unfamiliar terrain. Be alert to changing terrain conditions.
- Never operate on excessively rough, slippery, or loose terrain.
- Always follow proper turning procedures as described in this manual. Practice turning at low speeds before attempting to turn at faster speeds. Do not turn at excessive speeds.
- Always have the Tractor inspected by an authorized dealer if it's been involved in an accident.
- Never operate on hills too steep for the Tractor or for your abilities. Practice on smaller hills before attempting larger hills.
- Always follow proper procedures for climbing hills. Check the terrain carefully before ascending a hill. Never climb hills with excessively slippery or loose surfaces. Shift your weight forward. Never open the throttle suddenly or make sudden gear changes. Never go over the top of a hill at high speed.

- Always follow proper procedures for going downhill and for braking on hills. Check the terrain carefully before you start down a hill. Shift your weight backward. Never go down a hill at high speed. Avoid going down a hill at an angle, which would cause the vehicle to lean sharply to one side. Travel straight down the hill when possible.
- Always follow proper procedures for crossing the side of a hill. Avoid hills with excessively slippery or loose surfaces. Shift your weight to the uphill side of the Tractor. Never attempt to turn the Tractor around on any hill until you' ve mastered (on level ground) the turning technique outlined in this manual. Avoid crossing the side of a steep hill when possible.
- Always use proper procedures if you stall or roll backwards while climbing a hill. To avoid stalling, maintain a steady speed when climbing a hill. If you stall or roll backwards, follow the special procedure for braking described in this manual. Always dismount on the uphill side, or to either side if the Tractor is pointed straight uphill. Turn the Tractor around and remount following the procedure described in this manual.

- Always check for obstacles before operating in a new area. Never attempt to operate over large obstacles, such as rocks or fallen trees. Always follow proper procedures when operating over obstacles as described in this manual.
- Always be careful of skidding or sliding. On slippery surfaces like ice, travel slowly and use extra caution to reduce the chance of skidding or sliding out of control.
- Avoid operating the Tractor through deep or fast-flowing water. If it's unavoidable, travel slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do not make sudden turns or stops, and do not make sudden throttle changes.
- Wet brakes may have reduced stopping ability. Test your brakes after leaving water. If necessary, apply them lightly several times to allow friction to dry out the pads.

CAUTION

Brake discs can be overhot after continuous braking. Allow brake disc to cool before serving.

- Risks related to contact with hot surfaces,including residual risks such as filling of oil or coolant in hot engines or transmissions.
- Always check for obstacles or people behind the Tractor before operating in reverse. When it s safe to proceed in reverse, move slowly and avoid turning at sharp angles.

- Always use the size and type of tires specified for your Tractor, and always maintain proper tire pressure.
- Never modify an Tractor through improper installation or use of accessories.
- Never exceed the stated load capacity for your Tractor. Cargo must be properly distributed and securely attached. Reduce speed and follow the instructions in this manual for carrying cargo or towing. Allow a greater distance for braking.
- Always remove the ignition key when the vehicle is not in use to prevent unauthorized use or accidental starting.
- Child or pets shall not be carried on the racks.
- Never touch running parts, such as wheels, drive shaft, etc.

FOR MORE INFORMATION ABOUT TRACTOR SAFETY, PLEASE CONTACT WITH YOUR DEALER.

Equipment Modifications

We are concerned with the safety of our customers and for the general public. Therefore, we strongly recommend that consumers do not install on an Tractor any equipment that may increase the speed or power of the vehicle, or make any other modifications to the vehicle for these purposes. Any modifications to the original equipment of the vehicle create a substantial safety hazard and increase the risk of body injury. The warranty on your Tractor is terminated if any equipment has been added to the vehicle, or if any modifications have been made to the vehicle, that increase its speed or power.

NOTE

The addition of certain accessories, including (but not limited to) mowers, blades, tires, sprayers, or large racks, may change the handling characteristics of the vehicle. Use only approved accessories, and familiarize yourself with their function and effect on the vehicle.

Avoid Burns from Hot Parts

Certain components become hot during operation. Avoid contact with those parts during and shortly after operation to avoid burns.

Pulling a Trailer

Check the maximum axle loads of the vehicle identification plate (statutory plate). CFMOTO tractor can tow a trailer on the road. Check the trailer, the maximum loads on the identification plate. Check the national packages limits the use of a tractor-trailer on the road. Connect the trailer lights and set the slow moving vehicle triangle behind the trailer.

NOTE

A CFMOTO approved rear hitch must be properly installed on the vehicle for hauling trailers.

Riding this vehicle with a trailer substantially increases the risk of toppling, especially on inclined slopes. If a trailer is used behind the vehicle make sure that its hitch is compatible with the one on the vehicle. Make sure the trailer is horizontal with the vehicle. (In some instances a special extension may have to be installed on the vehicle hitch). Use security chains or cables to secure the trailer with the vehicle.

Reduce your speed when pulling a trailer and turn gradually. Avoid hills and rough terrain. Never attempt steep hills. Allow more distance for braking, especially on inclined surfaces and when a passenger is on board. Be careful not to skid or slide.

If a trailer is used behind the vehicle make sure that its hitch is compatible with the one on the vehicle. Make sure the trailer is horizontal with the vehicle. (In some instances a special extension may have to be installed on the vehicle hitch). Use security chains or cables to secure the trailer with the vehicle. This vehicle may require additional stopping distance if hauling heavy loads, especially on inclined surfaces and when a passenger is on board. Improperly loading a trailer may cause loss of control. Respect the recommended maximum hauling capacity and maximum tongue load. Make sure there is at least some weight on the tongue.

Always make sure load is evenly distributed and safely secured on the trailer; an evenly balanced trailer is easier to control. Always put the shift lever to L (low range) for hauling a trailer in addition to providing more torque, operating in low range helps account for the increased load on the rear tires. When stopped or parked, block the vehicle and trailer wheels from possible move- ment. Use caution when disconnecting a loaded trailer; it or its load may topple on you or others. When hauling a trailer, respect the following maximum hauling capacity.

MAXIMUM HAULING CAPACITY						
TRAILER LOAD ALLOWED		TONGUE WEIGHT ALLOWED	NOTE			
CF400ATR-2S CF500ATR-2S	260 kg	25 kg	Trailer	Includes trailer and trailer load. Ensure to properly load the trailer so		
CF400ATR-2L CF500ATR-2L	300 kg	25 kg	without brakes	that tongue is always pushing on hitch support and not pulling on hitch ball.		

NOTE: Includes trailer and trailer load. Ensure to properly load the trailer so that tongue is always pushing on hitch support and not pulling on hitch ball.

⚠ WARNING

Stay clear from the area between tractor and trailed vehicle.

A WARNING

Strictly follow the instructions outlined in the operator s manual of the mounted or trailed machinery or trailer, and not to operate the combination tractor - machine or tractor - trailer unless all instructions have been followed.

Place a support under vehicle.

NOTE: Before jacking ensure that all wheels are locked.

NOTE When the brake lock is applied ensure that the vehicle stays securely in place.



TYPICAL FRONT UP POINT LOCATION

WARNING

DO NOT OVERLOAD your jack beyond its rated capacity. Use jack which is designed for use on hard level surfaces only. Use lifting device only. DO not move or dolly the vehicle while on the jack. Refer to jack warnings and operating instructions prior to use.

NOTE: Ensure that 4 WH is engaged and brake is locked.



TYPICAL BACK UP POINT LOCATION

INTENDED USE The tractor is designed solely for use in agricultural or similar operations. Use in any other way is considered as contrary to the intended use. Compliance with and strict adherence to the conditions of operation, service, and repair as specified by the manufacturer, also constitute essential elements of the intended use. The tractor should be operated, serviced, and repaired only by persons who are familiar with its particular characteristics and who are acquainted with the relevant safety procedures. Accident prevention regulations, all other generally recognized regulations on safety and occupational medicine, and all road traffic regulation must be observed at all times. Any arbitrary modifications carried out to this tractor may relieve the manufacturer of liability for any resulting damage or injury. The agricultural tractors can not be used in conditions which may cause the risk of contact with hazardous substances, e.g. spraying of pesticides. In addition, the agricultural tractors also can not used in conditions which may risk of falling and penetrating objects.

Hauling a Load (if Equipped with Hitch)

Never pull a load by attaching it to the cage; this can cause the vehicle to tip over. Use only the trailer hitch (ifi n-stalled) to pull a load.

In an emergency situation, use the recovery hook to recover a stuck vehicle.

When pulling loads with a chain or cable, ensure that there is no slack before starting and maintain tension while pulling.

When pulling loads with a chain or cable, be sure to brake progressively. The inertia of the load could lead to an impact.

When hauling a load, respect the maximum hauling capacity. See *PULLING A TRAILER* subsection.

A WARNING

Slack can cause the chain or cable to break and snap back.

When pulling another vehicle, be sure that someone is controlling the pulled vehicle. They must brake and steer to prevent the vehicle from going out of control.

Reduce your speed when hauling a load and turn gradually. Avoid hills and rough terrain. Never attempt steep hills. Allow more distance for braking, especially on inclined surfaces and when a passenger is on board. Be careful not to skid or slide.

Accessories and Modifications


If no such attachment points are foreseen, the operator s manual shall prohibit the installation of a frontend loader

This T3 has not attachment points for frontend loader. Do not install front loader

Where a designated attachment point is provided on the towbar:


Either:


a) Pass the cable through the attachment point and clip it back on itself (FIG.1)



Or:

b) Attach the clip directly to the designated point (Fig.2). This alternative must be specifically permitted by the trailer manufacturer since the clip may not be sufficiently strong for use in this way.





AWARNING

POTENTIAL HAZARD

Operating this Tractor without proper instruction.

WHAT CAN HAPPEN

The risk of an accident is greatly increased if the operator does not know how to operate the Tractor properly in different situations and on different types of terrain.

AWARNING

POTENTIAL HAZARD

Failure to follow the age recommendations for this Tractor.

Dismantling and disposal Caution ALWAYS BE ENVIRONMENTALLY RESPONSIBLE Follow the guidelines of the governmental agency for the proper disposal of hazardous materials such as engine oil, fuel, engine coolant and machine fluid, grease. Never disposal of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into groundwater or waterways. Failure to follow these procedures may seriously harm the environment. Comply with legal regulations and guidelines for disposal of: empty containers for fuel, cooling water (coolant), oil, grease; fuel/oil filters; battery; machine itself; machine accessories; and packaging materials.

HOW TO AVOID THE HAZARD

Never carry 2 or more passengers on this Tractor.

AWARNING POTENTIAL HAZARD

Carrying a passenger in the rear rack.

WHAT CAN HAPPEN


A passenger riding in the rear rack could be ejected from the vehicle unexpectedly or may contact moving components, both of which can result in severe injury or death.

HOW TO AVOID THE HAZARD

Never allow passengers to ride in the rear rack.

POTENTIAL HAZARD

Operating this Tractor without wearing an approved helmet, eye protection.



And protective clothing.

WHAT CAN HAPPEN

Operating an Tractor without an approved helmet increases the risk of a severe head injury or death in the event of an accident. Operating without eye protection could result in an accident and could increase the chance of a severe eye injury in the event of an accident.




Always wear an approved helmet that fits properly.

Always wear eye protection (goggles or face shield), gloves, long-sleeved shirt or jacket, and long pants.

AWARNING

POTENTIAL HAZARD



Operating the Tractor after consuming alcohol or drugs.

WHAT CAN HAPPEN

Consumption of alcohol and/or drugs could seriously affect operator judgment. Reaction time may be slower and operator balance and perception could be affected. Consumption of alcohol and/or drugs before or while operating an Tractor could result in an accident causing severe injury or death.



HOW TO AVOID THE HAZARD

Never consume alcohol or drugs before or while operating an Tractor.

AWARNING

POTENTIAL HAZARD

Operating the Tractor at excessive speeds.

WHAT CAN HAPPEN

Excessive speed increase the operator's chance of losing control of the Tractor, which can result in an accident.

HOW TO AVOID THE HAZARD

Always operate the Tractor at a speed that's proper for the terrain, visibility and operating conditions, and your experience.

AWARNING

POTENTIAL HAZARD

Attempting wheelies, jumps and other stunts.

WHAT CAN HAPPEN

Attempting stunts increases the chance of an accident, including an overturn.


HOW TO AVOID THE HAZARD

Never attempt wheelies, jumps, or other stunts. Avoid exhibition driving.

AWARNING

POTENTIAL HAZARD

Failure to inspect the Tractor before operating. Failure to properly maintain the Tractor.



WHAT CAN HAPPEN

Poor maintenance increases the possibility of an accident or equipment damage.

HOW TO AVOID THE HAZARD

Always inspect your ATV before each use to make sure it's in safe operating condition.

Always follow the inspection and maintenance procedures and schedules described in the owner's manual.

AWARNING

POTENTIAL HAZARD

Removing hands from the handlebars or feet from the footrests during operation.

WHAT CAN HAPPEN

Removing even one hand or foot can reduce ability to control the vehicle or could cause loss of balance and ejection from the Tractor.

If the operator's foot is not firmly planted on the footrest, it could come into contact with the rear wheels and lead to accident or injury.

HOW TO AVOID THE HAZARD

Always keep both hands on the handlebars and both feet on the footrests of the Tractor during operation.

AWARNING

POTENTIAL HAZARD


Failure to use extra caution when operating the Tractor on unfamiliar terrain.

WHAT CAN HAPPEN

Unfamiliar terrain may contain hidden rocks, bumps, or holes that could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Travel slowly and use extra caution when operating on unfamiliar terrain. Always be alert to changing terrain conditions.



AWARNING

POTENTIAL HAZARD

Failure to use extra caution when operating on excessively rough, slippery or loose terrain.

WHAT CAN HAPPEN

Operating on excessively rough, slippery or loose terrain could cause loss of traction or loss of control, which could result in an accident or overturn.



Do not operate on excessively rough, slippery or loose terrain until you' ve learned and practiced the skills necessary to control the Tractor on such terrain. Always use extra caution on rough, slippery or loose terrain.

AWARNING

POTENTIAL HAZARD

Turning improperly.

WHAT CAN HAPPEN

Improper turns could cause loss of control and lead to a collision or overturn.



HOW TO AVOID THE HAZARD

Always follow proper procedures or turning as described in the owner's manual. Practise turning at slow speeds before attempting to turn at faster speeds.

Never turn at excessive speed.

AWARNING

POTENTIAL HAZARD

Operating on excessively steep hills.

WHAT CAN HAPPEN

The vehicle may overturn.

HOW TO AVOID THE HAZARD

Never operate on hills too steep for the Tractoror for your abilities. Never operate the Tractor on hills steeper than 20°

Practice on smaller hills before attempting large hills.

AWARNING

POTENTIAL HAZARD

Climbing hills improperly.

WHAT CAN HAPPEN

Improper hill climbing could cause loss of control or overturn.


HOW TO AVOIDL THE HAZARD

Always follow proper procedures for climbing hills as described in the owner's manual.

Always check the terrain carefully before ascending any hill.

Never operate the Tractor on hills steeper than 20°. Never climb hills with excessively slippery or loose surfaces. Shift your weight forward. Never open the throttle suddenly while traveling uphill.

The Tractor could flip over backwards. Never go over the top of any hill at high speed. And obstacle, a sharp drop, or another vehicle or person could be on the other side of the hill.



AWARNING

POTENTIAL HAZARD


Traveling downhill improperly.

WHAT CAN HAPPEN

Improperly descending a hill could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for travelling down hills as described in the owner's manual.



NOTE

A special technique is required when braking while traveling downhill. See page 86. Always check the terrain carefully before descending a hill. Shift your weight backward. Never travel down a hill at high speed. Avoid traveling down a hill at an angle, which would cause the vehicle to lean sharply to one side. Travel straight down the hill when possible.

AWARNING

POTENTIAL HAZARD

Improperly crossing hills and turning on hills

WHAT CAN HAPPEN

Improperly crossing or turning on hills could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Never attempt to turn the ATV around on any hill until you' ve mastered the turning technique (on level ground) as described in the owner's manual. See page 82.



Use extra caution when turning on any hill. Avoid crossing the side of a steep hill.

WHEN CROSSING THE SIDE OF A HILL:

Always follow proper procedures as described in the owner's manual.

Avoid hills with excessively slippery or loose surfaces. Shift your weight to use uphill side of the Tractor.

AWARNING

POTENTIAL HAZARD

Stalling, rolling backwards or improperly dismounting while climbing a hill.

WHAT CAN HAPPEN

The vehicle could overturn.

HOW TO AVOID THE HAZARD


Maintain steady speed when climbing a hill

IF ALL FORWARD SPEED IS LOST:

Keep your weight uphill. Apply the front brake. When fully stopped, apply the rear brake as well, then shift the gear to parking.

IF THE ATV BEGINS ROLLING BACKWARDA:

Keep weight uphill. Never apply engine power.



Never apply the rear brake while rolling backwards. Apply the front brake. When fully stopped, apply the rear brake as well, and shift the gear to parking.

Dismount on uphill side, or to either side if Tractor is pointed straight uphill.

Turn the **Tractor** around and remount, following the procedure described in the owner's manual. See Page 93.

AWARNING

POTENTIAL HAZARD

Improperly operating over obstacles.

WHAT CAN HAPPEN

Operating over obstacles could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Before operating in a new area, check for obstacles.

Avoid operating over large obstacles such as rocks and fallen trees when possible. If unavoidable, use extreme caution and always follow proper procedures as outlined in the owner's manual.

AWARNING

POTENTIAL HAZARD

Skidding or sliding.

WHAT CAN HAPPEN

Skidding or sliding can cause loss of control. If the tires regain traction unexpectedly, the Tractor could overturn

HOW TO AVOID THE HAZARD

On slippery surface such as ice, travel slowly and use extra caution to reduce the chance of skidding or sliding out of control.

AWARNING

POTENTIAL HAZARD

Overloading the Tractor or carrying/towing cargo improperly.

WHAT CAN HAPPEN

Overloading and towing can cause changes in vehicle handling, which could lead to loss of control or an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated load capacity for this Tractor.

Cargo should be properly distributed and securely attached. Reduce speed when carrying cargo or pulling a trailer. Allow a greater distance for braking.

Always follow the instructions in the owner's manual for carrying cargo or pulling a trailer. See page 79.

AWARNING

POTENTIAL HAZARD

Operation the Tractor through deep or fasten-following water.

WHAT CAN HAPPEN

Tires may float, causing loss of traction and loss of control, which lead to an accident or overturn.

HOW TO AVOID THE HAZARD

Avoid operating the Tractor through deep or fast-flowing water. If it is unavoidable to enter water that exceeds the recommended maximum depth (see page 88), travel slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do not make sudden turns or stops, and do not make sudden throttle changes. Wet brakes may have reduced stopping ability. Always test the brakes after leaving water. If necessary, apply brakes several times to dry out the pads.

AWARNING

POTENTIAL HAZARD

Improperly operating in reverse.

WHAT CAN HAPPEN

The Tractor could collide with an obstacle or person, resulting in severe injury.

HOW TO AVOID THE HAZARD

Before shifting into reverse gear, always check for obstacles or people behind the Tractor. When it's safety to proceed, back slowly.

AWARNING

POTENTIAL HAZARD

Operating this Tractor with improper tires, or with improper or uneven tire pressure.

WHAT CAN HAPPEN

Use of improper tires, or operation of the Tractor with improper or uneven tire pressure, could cause loss of control or accident.

HOW TO AVOID THE HAZARD

Always use the size and type of tires specified in the owner's manual for the Tractor. Always maintain proper tire pressure.

AWARNING

POTENTIAL HAZARD

Operating the Tractor with improper modifications.

WHAT CAN HAPPEN

Improper installation of accessories or modification of the Tractor may cause changes in handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never modify the Tractor through improper installation or use of accessories. All parts and accessories added to the vehicle must be genuine parts or equivalent components designed for use on this Tractor and should be installed and used according to approved instructions. Consult your dealer for more information.

AWARNING

POTENTIAL HAZARD

Operating on frozen bodies of water.

WHAT CAN HAPPEN

Severe injury or death can result if the Tractor and or the operator fall through the ice.

HOW TO AVOID THE HAZARD

Never operate the Tractor on a frozen body of water.

AWARNING

Leaving the keys in the ignition can lead on unauthorized use of the vehicle resulting in serious injury or death. Always remove the ignition key when the vehicle is not in use.

AWARNING

After any overturn or accident, have a qualified service dealer inspect the entire vehicle for possible damage, including (but not limited to) brakes, throttle and steering systems.

AWARNING


Safe operation of this rider-active vehicle requires good judgement and physical skills.

Persons with cognitive or physical disabilities who operate this vehicle have an increased risk of overturn and loss of control, which could result in severe injury or death.

AWARNING

Exhaust system components are very hot during and after use of the vehicle. Hot components can cause serious burns and fire. Do not touch hot exhaust system components. Always keep combustible materials away from the exhaust system. Use caution when traveling through tall grass, especially dry grass.

Warning decals have been placed on the Tractor for your protection. Read and follow the instructions on each decal carefully. If a decal becomes illegible or comes off, contact your dealer to purchase a replacement.



1

A WARNING

NEVER carry passengers on this carrier or on ATV MAXIMUM LOAD: 20 kg (44.1lbs)

CF400ATR-2S/CF500ATR-2S

A WARNING

NEVER carry passengers on this carrier

MAXIMUM LOAD: 20 kg (44.1lbs)

CF400ATR-2L/CF500ATR-2L

(2)

A WARNING

NEVER carry passengers on this carrier or on ATV MAXIMUM LOAD: 40 kg (88.2 lbs)

CF400ATR-2S/CF500ATR-2S

A WARNING

NEVER carry passengers on this carrier

MAXIMUM LOAD: 40 kg (88.2 lbs)

CF400ATR-2L/CF500ATR-2L

▲ WARNING

Improper loading of a trailer may cause loss of vehicle control, resulting in severe injury or death.

- Maximum unbraked towing mass 260 kg (573 lbs).
- Maximum unbraked tongue mass 25 kg (55 lbs)

9GQS-190101-1

CF400ATR-2S/CF500ATR-2S

AWARNING

Improper loading of a trailer may cause loss of vehicle control, resulting in severe injury or death.

- Maximum unbraked towing mass 300kg (661 lbs).
- Maximum unbraked tongue mass 25 kg (55 lbs)

9CRF-190101 EU179

CF400ATR-2L/CF500ATR-2L

4

A WARNING



NEVER ride as a passenger.

Passengers can cause a loss of control, resulting in SEVERE INJURY or DEATH.

9GQ0-190103 EU151

CF400ATR-2S/CF500ATR-2S

A WARNING



Passengers under 12 are prohibited. Passenger should be well seated & hold tight the handgrip during public road operation.



Passenger seat could be used during public roads operation. Passenger seat shall not be used during field operation.

9GO2-190101 FU16

CF400ATR-2L/CF500ATR-2L

(5)

NOTICE

Check engine oil every 500 kilometers (310 miles) Vérifier le niveau d'huile moteur tous les 500 kilomètres (310 miles)

905B-190413-US13C

(6)

A WARNING

Improper tire pressure or overloading can cause loss of control.

Loss of control can result in severe injury or death.

Cold tire pressure:

Front: **6.5** psi(**45** kPa)

Rear: 6.5 psi(45 kPa)

9CR6-190101 EU1310

 $\overline{7}$

A WARNING



Operating this ATV if you are under the age of 16 increases your chance of severe injury or death.

NEVER operate this ATV if you are under age 16

(8)

CF400ATR-2S/CF500ATR-2S

A WARNING

Improper ATV use can result in SEVERE INJURY or DEATH.







ALWAYS USE AN APPROVED HELMET AND **PROTECTIVE GEAR**

PASSENGERS

WITH DRUGS OR ALCOHOL

NEVER operate :

- without proper training or instruction.
- · at speeds too fast for your skills or the conditions.
- with a passenger-passengers affect balance and steering and increase risk of losing control.

ALWAYS:

- use proper riding techniques to avoid vehicle overturns on hills and rough terrain and in turns.
- avoid paved surfaces-pavement may seriously affect handling and control.

LOCATE AND READ OWNER'S MANUAL. FOLLOW ALL INSTRUCTIONS AND WARNINGS.

9GQ0-190102 EU151

(8) CF400ATR-2L/CF500ATR-2L

A WARNING

Improper ATV use can result in SEVERE INJURY or DEATH.



ALWAYS USE AN APPROVED HELMET AND PROTECTIVE GEAR



NEVER USE WITH DRUGS OR ALCOHOL

NEVER operate:

- without proper training or instruction.
- at speeds too fast for your skills or the conditions.

ALWAYS:

- use proper riding techniques to avoid vehicle overturns on hills and rough terrain and in turns.
- avoid paved surfaces-pavement may seriously affect handling and control.

LOCATE AND READ OWNER'S MANUAL. FOLLOW ALL INSTRUCTIONS AND WARNINGS.

7020-190104 EU1104

9

DRIVE SELECT LEVER

- Read owner's manual carefully before operating.
- ATV MUST be stopped before shifting select lever.
- Shifting into or from reverse or park is impossible without applying rear brake

(10)

A WARNING

Turning the vehicle in 4WD-LOCK ("DIFF.LOCK") takes more effort.

Operate at a slow speed and allow extra time and distance for maneuvers to avoid loss of control.

9010-190002 US1310

(11)

CF400ATR-2L/CF500ATR-2L

A WARNING



Never carry more than one pass enger! Never drive with a pass enger unless pass enger seat is securely in place! Passe nger must hold firmly the handgrips during riding!

13



Bleifreies Benz in Unleaded fuel only Carburant sans plomb Gasol ina sin plomo Bez olovnatý benzin Endas t blyfri bensin

RON/ROZ min. 95

(12)

A WARNING

NEVER attach here or on the luggage rack to pull a load This can cause the vehicle to tip over. AL-WAYS use the trailer hitch or the recovery hook to pull a load.



9CR0-190102 EU153

Safety decals and locations Safe riding gear


Always wear clothing suited to the type of riding .Tractor riding requires special protective clothing for comfort and to reduce the chance of injury.

1. Helmet

Your helmet is the most important piece of protective gear for safe riding. An approved helmet can prevent a severe head injury.

2. Eye protection

Do not depend on sunglasses for proper eye protection. A pair of goggles or a helmet face shield offers the best protection for your eyes. They should be kept clean and be shatterproof design.



Safety decals and locations Safe riding gear

3. Gloves

Off-road style gloves with knuckle pads are the best for comfort and protection.

4. Boots

The best footwear is a pair of strong over-the-calf boots with heels, like moto-cross boots.

5. Clothing

Always wear long sleeves and long pants to protect arms and legs. Riding pants with kneepads and a jersey with shoulder pads provide the best protection.


Features & Controls Electrical Switches

AWARNING

Pressing the override button while the throttle is open can cause loss of control, which may result in severe injury or death. Always release the throttle before pressing the override button.

1) Override Button

Top speed is normally limited when operating in 4WD-LOCK and REVERSE. If conditions require more engine power when proceeding, press this button to override the speed limiting function. (See page 58 ~ 61 for a detailed explanation about the front diff-lock switch and its function.) Releasing the button restores the speed limiting function. While this button is depressed, the override indicator light will come on.



2Headlight Switch

The headlight switch consists of 4 positions: " $\equiv \bigcirc$ " \ " $\equiv \bigcirc$ " \ "OFF".

- When the switch is at this position, Lo beam, front pilot light, tail light, license plate light and instrument light are on.

OFF: When the switch is at this position, tail light, license plate light are off, daytime running lamps are on.

3 Turn Switch

Move the switch to \leftarrow left turn light and left turn signal indicator are on.

Move the switch to \Rightarrow right turn light and right turn signal indicator are on.

(4) Hazard Switch

Depress the button front turn lights, rear turn lights and turn signal indicators on dashboard are on.

CAUTION

Don't use the headlights with the engine turned off for more than 15 minutes. The battery may discharge to the point that the starter motor will not operate properly. If this should happen, remove the battery and recharge it.

5Horn Button

Press this button, the horn will sound.

6 Engine Stop Switch

When the switch is at , the engine shuts off.

When the switch is at \bigcirc , the engine can be started.


7Starter Switch

When the main switch is turned to ON, and the engine stop switch is at \bigcirc , push this button to start the engine.

Brake

Front Brake Lever

The front brake lever ① is located on the right handlebar. Put it toward the handlebar to apply the front brake.



Features & Controls Brake Pedal and Lever

Brake pedal is located on the right side of the vheicle. Push down on the pedal to apply both the front and rear brakes.

Rear brake lever 2 (If equipped) is located on the left handlebar. Pull the lever toward the handlebar to apply rear independent brakes.

Adjust switch (3) if you need parking brake when vehicle comes to a full halt.








AWARNING

Auxiliary parking brake can not be used in sloping road.

master cylinder fluid level before riding. When squeezed, the lever or pedal should feel firm. Any sponginess would indicate a possible fluid leak or low master cylinder fluid level, which must be corrected before riding. Contact your dealer for proper diagnosis and repairs.

Brake Fluid

Check the brake fluid level in the front brake master cylinder and in the brake fluid reservoir before each use of the Tractor. The front brake master cylinder is located on the right handlebar. The brake fluid reservoir is near the right passanger foot rest. The front brake fluid level can be seen through an indicator window on the side of the master cylinder. When fluid level is lower than the ① "lower" mark, refill with the same type of brake fluid.



AWARNING

An over-full master cylinder may cause brake drag or brake lock-up, which could result in serious injury or death. Maintain brake fluid at the recommended level. Do not overfill.

NOTE

When checking the fluid level, the Tractor must be on level ground with the handlebars straight. If fluid level is lower than the ① "lower" mark, add DOT3 or DOT4 brake fluid. Don't overfill.



AWARNING

Never store or use a partial bottle of brake fluid. Brake fluid is hygroscopic, meaning it rapidly absorbs moisture from the air. The moisture causes the drop of boiling temperature of the brake fluid, which can lead to early brake fade and the possibility of accident or severe injury. After opening a bottle of brake fluid, always discard any unused portion.

Features & Controls Parking Brake

When parking, stop the engine and shift the gear selector Lever ② into the park position. (**CAUTION**: When shifting the transmission in PARK, always push the brake pedal) Shake the vehicle forward and backward to check if the parking brake is engaged.



Important Safeguards

• Never depend on the parking brake alone if the Tractor is parked on a hill. Always block the wheels on the downhill side of the Tractor to prevent rolling. It's recommended to park the Tractor on a level ground.

• Fuel Tank

Tighten the cap fuel tank with right-handed rotation in the fuel tank.



Fuel safety

AWARNING

Gasoline is highly flammable and explosive under certain conditions.

- •Always exercise extreme caution whenever handling gasoline.
- •Always refuel with the engine stopped, and outdoors or in a well ventilated area.
- •Never carry a plastic container with gasoline in the racks while riding. Static electricity between the rack and container could cause a spark.
- •Do not smoke or allow open flames or sparks in or near the area where refueling is performed or where gasoline is stored.
- •Do not overfill the tank. Do not fill the tank neck.
- •If gasoline spills on your skin or clothing, immediately wash it off with soap and water and change clothing.
- Never start the engine or let it run in an enclosed area. Engine exhaust fumes are poisonous and can cause loss of consciousness or death in a short time.

AWARNING

The engine exhaust from this product contains chemicals known to cause cancer, birth defects or other reproductive harm. Operate this vehicle only outdoors or in well-ventilated areas.

• Automatic Transmission Gear Selector

The transmission gear selector ① is located on the left side of the vehicle.

L: Low Gear

H: High Gear

N: Neutral

R: Reverse


P: Parking



When shifting among N, R, P, you must push the brake pedal.


This Tractor is equipped with an on-command four-wheel drive switch "2WD" /" 4WD" ① and a front diff-lock switch "LOCK" /" 4WD" ②. Select the appropriate drive according to terrain and the conditions.

- Two-wheel drive (2WD): Power is supplied to the rear wheels only.
- Four-wheel drive (4WD): Power is supplied to the rear and front wheels.
- Four-wheel drive with the front diff locked (4WD-LOCK): Power is supplied to the rear and front wheels when the front diff is locked. Unlike the 4WD mode, all wheels turn at the same speed.




• on-command four-wheel drive switch

"2WD" /" 4WD" ②: To change from 2WD to 4WD, stop the Tractor, and then set the switch to "4WD". When the Tractor is in 4WD, the 4WD indicator "%" will come on in the dashboard display. To change from 4WD to 2WD, stop the Tractor, be sure the lever ①is moved to the front diff lock switch, and then set the switch ② to "2WD". When the Tractor is in 2WD, the 2WD indicator " " will come on in the dashboard display.



Front Diff-lock Switch "LOCK" /" 4WD" (1)

To lock the front diff in 4WD, make sure the on-command four-wheel-drive switch is set to 4WD, stop the Tractor, move the lever 2to 2WD/4WD switch, then set the switch 1 to LOCK, when the front diff is locked, the 4WD in lock indicator light " $\frac{\partial 4}{\partial k}$ " will come on .




NOTE

- •When the switch is set to "LOCK", the front diff-lock indicator light will flash until the front diff is locked.
- •When the indicator light is flashing, turning the handlebar left and right will help the front gear lock to engage.
- •Riding before the front diff lock is properly engaged (e.g., when the indicator light is flashing) will cause the engine speed to be limited until engagement is complete.
- •When the Tractor is in 4WD-LOCK, the maximum traveling speed is limited to 30 km/h (19 mph). However, if conditions require full engine power to be available, depress the override switch to disable the 4WD-LOCK speed limiter.

• Throttle Lever

Once the engine is running, movement of the throttle lever will increase the engine speed. Regulate the speed of the machine by varying the throttle position. Because the throttle is springloaded, the machine will decelerate, and the engine will return to an idle any time the hand is removed from the throttle lever. Before starting the engine, check the throttle to be sure it is




operating smoothly. Make sure it returns to the idle position as soon as the lever is released.

CAUTION

Check the operation of the throttle lever before you start the engine. If it does not work smoothly, check for the cause. Correct the problem before riding the Tractor. Consult your dealer if you can't find or solve the problem yourself.

Features & Controls Speed Limiter

The speed limiter keeps the throttle from fully opening, even when the throttle lever is pushed to the maximum. Turning in the 2 limits the maximum engine power available and decreases the maximum speed of the Tractor.




CAUTION

Do not turn the adjusting screw out more than 12 mm (0.47 in). Always make sure the throttle lever free play is adjusted to very easily $(0.12 \sim 0.20 \text{ in})$.

Main Switch

Functions of the respective switch positions are as follows:

: The engine can be started only at this position and the headlights and taillight come on when the light switch is on. The key can not be removed in this position.



Indicator and Warning Lights

①Turning Indicators: includes Left turning indicator and right turning indicator. Move the switch to \leftarrow left turn light and left turn signal indicator are on.

Move the switch to ⇒ right turn light and right turn signal indicator are on.

Depress the button <u>a</u> front turn lights, rear turn lights and turn signal indicators on dashboard are on. Please check the Page 50 for reference.

② Operator presence control: OPC

Vehicle will alarm immediately once the driver leaves the seat when the engine is running.

③ High Beam Indicator: ≣○

This indicator light comes on when moving the head light switch to ≣○

- ④ Brake failure indicator: **(①)**Brake failure indicator shows the red light when brake fluid leaks or lower than the standard level.
- 5 Gear Indicators: L, H, N, R

Lo Gear Indicator "L"

This indicator light comes on when the gear selector is in the L position.

Hi Gear Indicator "H"

This indicator light comes on when the gear selector is in the H position.

Neutral Indicator "N"

This indicator light comes on when the gear selector is in the N position.


Reverse Gear Indicator "R"

This indicator light comes on when the gear selector is in the R position.

⑥ Park Indicator " ℙ "

This indicator lights up when parking is engaged.

Please check the Page 58 for reference.



- (1) Turning Indicators
- ② Operator presence control
- 3 High Beam Indicator
- 4 Brake failure indicator
- **5** Gear Indicators
- ⑥ Park Indicator
- 7 EFI Indicator
- **® Override Indicator**

7 EFI Indicator:

This indicator light comes on when troubles occur in EFI system (Refer to page 156 for detailed information)

®OVERRIDE INDICATOR

This indicator light comes on when pressing the override switch. Always exercise caution to use override button.

Dashboard

- 1. Oil pressure warning light: When the engine lubrication oil pressure is abnormal, the light is on, and off when it's normal.

Tip: Only after the drive method have been switched will the wheel light indicator will on because the front gear case has the synchronizing apparatus.


- 3. Fuel gauge: show the gas remain in the tank, F means it.s full, E means the stand-by gas. And when the petrol indicator enter the red area, which means the gas that remained can drive for 50 km at most, need to be added as soon as possible.
- 4. Speed Indication Devices: Indicate the speed in number way, the work method can switch between metric and inch. Refer to Page 63.

- 5. Rider Information Center: This dashboard section can be toggled using the 'SEL' button to display the accumulated distance traveled in miles/kilometers; 'ODO' -The accumulated vehicle distance traveled, 'TRIP' - The trip distance traveled, 'RPM' - The engine speed in Revolutions Per Minute (RPM), 'H'- The engine hour meter records the engine running time, 'V' - Battery voltage, 'L-I-g-H—5' - Dashboard brightness (5 levels).
- 6. EPS indicator: When the bike is equipped with EPS system, the indicator light is on. Its working method and content refer to Page 156.
- 7. Coolant temperature gauge: Shows the current coolant temperature, C is the low temperature area. H is the high temperature area, Both overlow and overhigh are abnormal, Idle warm machine is need when it's too cold, and park the bike when it's too hot to prevent the coolant from being boiling. Keep the coolant temperature in a normal range.

NOTE

If the Tractor drive for a long time or in a slope with heavy load, which may lead to the engine overheat.

8. Clock indicator: Display the current time, whose method and adjustment refer to Page 50.



- ①Wheel drive indicator
- ⑤Rider Information Center
- 20il pressure warning light 6 EPS indicator

③Fuel gauge

- (7) Coolant temperature gauge
- 4 Speed Indication Devices ® Clock indicator

Dashboard Setting/Adjustment list

Item	Shows and display	key-operated switch	Result
Metric system/British system exchange	Speed/Mileage	Long press Key ①	Metric system←→British system
Mileage display exchange	Mileage ODO	Short press Key ①	$ODO \rightarrow TRIP \rightarrow RPM \rightarrow \cdots \rightarrow ODO$
Trip mileage cleaning	Mileage TRIP	Long press Key ${\mathbb Q}$	Trip mileage zero clearing
Time/hours adjustment	Time display	Short press Key ②	Hours progressive increase(0~12)
Time/Mintues adjustment	Time display	Long press Key ②	Mintues progressive increase (0~59)



Operation

Break-In Period

The break-in period for your new Tractor is very important, it is not only a simple action for you, which is as important as a proper break-in stated in manual. Careful treatment of a new engine will result in more efficient performance and longer life for the engine. Perform the following procedures carefully.

Operation

CAUTION

Do not load or tow cargo during the first 20 hours of use, do not operate at full throttle. It may damage engine parts or decrease engine life if excessively increase throttle during the first 20 hours of use.

Do not run engine with throttle over 1/2 open during the first 10 hours of use. Do not run engine with throttle over 3/4 open during the first 10 to 20 hours of use.

Operate this Tractor in normal condition after break-in period.

Use of any oils other than those recommended may cause serious engine damage. we recommend the use of special oil for 4–stroke engine: SAE 15W–40/SG.

Perform the following procedures before operation:

- 1. Fill the fuel tank with gasoline.
- 2. Put Tractor on a level surface to check the oil level. Add recommended oil if necessary to maintain the oil level between the minimum and maximum level marks of the dipsticks.
- 3. Drive slowly at first. Select an open area that allows room to familiarize yourself with vehicle operation and handling.
- 4. Vary throttle positions. Do not operate at sustained idle.
- 5. Perform regular checks on fluid levels, controls and areas outlined on the daily pre-ride inspection checklist. See page 71.

Operation

- 6. Pull only light loads.
- 7. During the break-in period, change both the oil and oil filter at 20 hours or 750km.

Pre-Ride Inspection

AWARNING

If a proper inspection is not done before each use, severe injury or death could result. Always inspect the vehicle before each use to ensure it is in proper operating condition.

Pre-Ride Checklist				
Item	Remarks	See Page		
Brake system/ lever travel	Ensure proper operation	51, 124		
Brake fluid	Ensure proper level	54		
Front suspension	Inspect, lubricate if necessary	134		
Rear suspension	Inspect, lubricate if necessary	134		

Pre-Ride Checklist					
Item	Remarks	See Page			
	necessary				
Steering	Ensure free operation				
Tires	Inspect condition and pressure	157			
wheels / fasteners	Inspect, ensure fastener tightness	128, 129			
Frame nuts, bolts, fasteners	Inspect, ensure fastener tightness				
Fuel and oil	Ensure proper levels	104			
Coolant level	Ensure proper levels	110			
Coolant hoses	Inspect for leaks				
Throttle	Ensure proper operation	121			
Gear shifting	Ensure proper operation				
Indicator lights/ switches	Ensure proper operation	64, 65			

Pre-Ride Checklist						
Item Remarks						
Air filter	Inspect, clean	116				
Air box sediment tube	Drain deposits whenever visible					
Headlamp	Check operation	132				
Brake light/tail lamp	Check operation	133				
Riding gear	Wear helmet, gloves, protective clothing	47				

Operation Starting the Engine Starting a Cold Engine

AWARNING

Engine exhaust contains poisonous carbon monoxide and can cause loss of consciousness resulting in severe injury or death. Never run an engine in an enclosed area.

CAUTION

Operating the vehicle immediately after starting could cause engine damage. Allow the engine to warm up for several minutes before operating the vehicle.

Starting a Cold Engine

- 1. Apply the rear brake pedal.
- 2. Turn ignition switch to "()", turn stop switch to "ON".
- 3. Shift gear selector into the neutral position.

NOTE

• When the gear selector is in neutral position, if indicator light on dashboard does not come on, ask your dealer to inspect its electric circuit or adjust gear-shifting system.

- Engine can be started in any gear if rear brake pedal is applied. However it is recommended to shift into neutral or park before starting the engine.
- 4. Completey close throttle lever and start the engine by pushing the start switch.
- If the engine fails to start, release the start switch, then push the start switch again. Pause a few seconds before the next attempt. Each cranking should be as short as possible to preserve battery energy. Do not crank the engine more than 10 seconds on each at tempt.
- If the battery is discharged, disassemble the battery to recharge.
- 5. Continue warming up the engine until it idles smoothly before starting the Tractor.

CAUTION

See the "Break-In Period" section prior to operating the engine for the first time.

• Gear selector operation and reverse driving

CAUTION

Before shifting, you must return the throttle lever to the closed position and stop the Tractor. Otherwise, the transmission may be damaged.

Shifting: Neutral to High

- 1. Return the throttle lever to the closed position and stop the Tractor.
- 2. shift to "H"(High) by moving the gear selector along the shift guide.

NOTE

Make sure that the gear selector is completely shifted into position.

3. Open the throttle lever gradually.

Shifting: High to Low

- 1. Return the throttle lever to the closed position and stop the Tractor completely.
- 2. Apply the rear brake pedal, shift to Low by moving the gear selector along the shift guide.



Shifting: Low to High

- 1. Return the throttle lever to the closed osition and stop the Tractor completely.
- 2. Shift to "H"(High) by moving the gear selector along the shift guide.

Shifting: Neutral(N) to Reverse®;

NOTE

The gear selector cannot be shifted into reverse (R) without applying the rear brake.

1. Return the throttle lever to the closed position and stop the ATV completely.

2. Apply the rear brake pedal, Shift the gear selector from "N" (neutral) to "R"(reverse) by moving

along the shift guide.

NOTE

- (a) When in reverse, the reverse indicator light should be on.
- ⓑ The indicator light should be on in accordance with actual gear position, if the light does not come on, ask your dealer to inspect.
- © Due to the synchronizing mechanism in the engine, the light may not come on until Tractor starts moving.
- 4. Check behind for people or obstacles, then release the rear brake pedal.
- 5. Open the throttle lever gradually and continue to watch rear while moving backward.

AWARNING

When you shift into reverse, make sure there are no obstacles or peois safeple behind you. When it is safe to proceed, go slowly.

shifting: Reverse to Park

- 1. Return the throttle lever to the closed position and stop the ATV completely.
- 2. Apply the rear brake pedal, Shift from reverse to park by moving the gear selection along the shift guide.

HAULING CARGO

AWARNING

Overloading the vehicle or carrying or towing cargo improperly can alter vehicle handling and may cause loss of control or brake instability. Always follow these precautions when hauling cargo:


- Never exceed the stated load capacity for this vehicle.
- Reduce speed.
- When operating over rough or hilly terrain, reduce speed and cargo to maintain stable driving conditions.
- Weight distribution in the rear rack should be as far forward and as low as possible. Carrying a high load raises the center of gravity and creates a less stable operating condition. Reduce load weight when cargo is high. When handling off-centered loads that cannot be centered, secure the load and operate with extra caution.
- All loads must be secured before operation. Unsecured loads may shift and create unstable operating conditions. which could result in loss of control of the vehicle. Always be sure that the rear rack is lowered.

- When operating with loads extending beyond the rack. Stability and maneuverability may be adversely affected, causing the machine to overturn.
- Carrying a load on only the front rack or the rear rack may cause an imbalanced condition and increases the possibility of vehicle overturn. Balance loads proportionally between the front rack and the rear rack, but do not exceed the stated load capacity.
- Use extreme caution when applying brakes with a loaded vehicle. Avoid terrain or situations that may require backing down-hill.
- Always attach the tow to the hitch point.
- The vehicle should never exceed 10 mph (16 km/h) while towing a load on a level surface. Vehicle speed should never exceed 5mph (8 km/h) when towing loads in rough terrain, while cornering, or while ascending or descending a hill.
- Do not obstruct the headlight when loading the front rack.

Load Distribution

Your Tractor has been designed to carry or tow a certain amount of load. Always read and understand the load distribution warnings listed on the warning labels, and never exceed the specified weights. Cargo weight should be mounted as low as possible. When operating over rough or hilly terrain, reduce speed and cargo to maintain stable driving conditions.

- 1. Always load the cargo as far forward as possible.
- 2. Always operate the vehicle with extreme caution whenever hauling or towing loads. Balance, handling, and control may be affected.
- 3. Slow down.



Driving Safely

Driving Procedures

- 1. Sit upright with both feet on the footrests and both hands on the handlebars.
- 2. Start the engine and allow it to warm up, apply the brakes, then shift the transmission into gear.
- 3. Check your surroundings and determine your path of travel.
- 4. Release the brakes.

- 5. Slowly depress the throttle with your right thumb and begin driving. Vehicle speed is controlled by the amount of throttle opening.
- 6. Drive slowly. Practice maneuvering and using the throttle and brakes on level surfaces.

Making Turns

To make a turn, steer in the direction of the turn, leaning your upper body to the inside of the turn while supporting your weight on the outer footrest. This technique alters the balance of traction between the wheels, allowing turn to be made smoothly. The same leaning technique should be used for turning in reverse.

NOTE

Practice making turns at slow speeds before attempting to turn at faster speeds.



AWARNING

Turning at sharp angles or at excessive speeds can result in vehicle overturn and lead to serious injury. Avoid turning at sharp angles. Never make turns at high speeds.

Driving on Slippery Surfaces


Whenever riding on slippery surfaces such as wet trails or loose gravel, or during freezing weather, follow these precautions:

- 1. Slow down when entering slippery areas.
- 2. Maintain a high level of alertness, reading the trail and avoiding quick, sharp turns which can cause skids.
- 3. Correct a skid by turning the handlebars in the direction of the skid and shifting your body weight forward.
- 4. Driving with AWD engaged can assist in controlling the vehicle in slippery areas.

CAUTION

Severe damage to drive train may occur if the AWD is engaged while the wheels are spinning.

Always engage AWD when the wheels have traction or are at rest.




AWARNING

Failure to exercise care when operating on slippery surfaces can result in loss of tire traction and cause loss of control, accident, and serious injury or death. Never apply the brakes during a skid. Do not operate on excessively slippery surfaces. Always reduce speed and use additional caution.

Driving Uphill

Whenever traveling uphill, follow these precautions:

- 1. Always travel straight uphill.
- 2. Avoid steep hills (20° maximum).
- 3. Keep both feet on the footrests.
- 4. Shift your weight forward.
- 5. Proceed at a steady rate of speed and throttle opening.
- 6. Remain alert and be prepared to take emergency action. This may include quick dismounting of the vehicle.



If all forward speed is lost:

Keep your weight uphill.

Apply the front brake. When fully stopped, apply rear brake as well, then shift gear selector into park position.

If the ATV begins rolling backwards:

Keep your weight uphill. Never apply engine power. Never apply the rear brake while rolling backwards. Apply the front brake. When fully stopped, apply the rear brake as well, and then shift gear selector into park position.

Dismount on uphill side, or to either side if Tractor is pointed straight uphill. Turn the Tractor around and remount, following the procedure described on page 87.

AWARNING

Braking and handling are greatly affected when operating in hilly terrain. Improper procedure could cause loss of control or overturn and result in serious injury or death.

Avoid climbing steep hills (20° maximum).

Use extreme caution when operating on hills, and follow proper operating procedures outlined in the owners manual.

Sidehilling

AWARNING


Improperly crossing hills or turning on hills can result in loss of control or vehicle overturn, resulting in severe injury or death. Avoid crossing the side of a hill when possible. Follow proper procedures as outlined in the owner's manual. Sidehilling can be a dangerous type of driving and should be avoided if at all possible. If you do enter into a situation where sidehilling is necessary, follow these precautions:

- 1. Slow down.
- 2. Lean into the hill, transferring your upper body weight toward the hill while keeping your feet on the footrests.

3. Steer slightly into the hill to maintain vehicle directions.

NOTE

If the vehicle begins to tip, quickly turn the front wheel downhill, if possible, or dismount on the uphill side immediately!




Driving Downhill

Whenever descending a hill, follow these precautions:

- 1. Proceed directly downhill.
- 2. Shift your weight to the rear of the vehicle.
- 3. Slow down.
- 4. Apply the brakes slightly to aid in slowing.

Familiarize yourself with operation of the auxiliary rear brakelever.



AWARNING

Excessive speed can cause loss of control and lead to serious injury or death. Always operate slowly when traveling downhill.


Turning Around on a Hill

AWARNING

Improper hill climbing procedures could cause loss of control or overturn and result in serious injury or death. Avoid climbing steep hills (20° maximum).

Use extreme caution when operating on hills, and follow proper operating procedures outlined in the owner s manual. If the vehicle stalls while climbing a hill, never back it down the hill!

One maneuver that can be used when it s necessary to turn around while climbing a hill is the K-turn:



- 1. Stop and shift the gear selector lever to the parking position while keeping body weight uphill.
- 2. Shut off the engine.
- 3. Dismount on the uphill side of the vehicle, or on the left if the vehicle is pointing straight uphill.
- 4. Staying uphill of the vehicle, turn the handlebars full left.
- 5. While holding the brake lever, shift the gear selector lever to the low gear position and slowly allow the vehicle to roll around to your right until it's pointing across the hill or slightly downward.
- 6. Shift the gear selector lever to the parking position and remount the vehicle from the uphill side, keeping body weight uphill.
- 7. Restart the engine, while holding the brake lever, shift the gear selector lever to low gear position.
- 8. Release the brake and proceed slowly, controlling speed with the brake, until the vehicle is on more level ground.

Driving Through Water

Your Tractor can operate through water with a maximum recommended depth equal to the bottom of the footrests . Follow these procedures when operating through water:

- 1. Determine water depths and current before crossing.
- 2. Choose a crossing where both banks have gradual inclines.



- 3. Proceed slowly, avoiding rocks and obstacles if possible.
- 4. After crossing, dry the brakes by applying light pressure to the lever until braking action is normal.

NOTE

Avoid operating the vehicle through deep or fast-flowing water. If you cannot avoid water that exceeds the recommended maximum depth, go slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do not make sudden turns or stops, and do not make sudden throttle changes.

After running the vehicle in water, it s critical to have it serviced as outlined in the maintenance chart. See page 123. The following areas need special attention: engine oil, transmission oil, front and rear gear cases and all grease fittings.

NOTE

If water has been ingested into the CVT, follow the procedure on page 119 for drying out the CVT. If your vehicle becomes immersed, and it s impossible to take it to your dealer before starting it, follow the steps described on page 136. Have the vehicle serviced by your dealer promptly.

AWARNING

Major engine damage can result if the vehicle is not thoroughly inspected after operation in water. Perform the services outlined in the maintenance chart.

If your vehicle becomes immersed or is operated in water that exceeds the footrest level, take it to your dealer for service before starting the engine.

Driving Over Obstacles

Be alert! Look ahead and learn to read the terrain. Be constantly alert for hazards such as logs, rocks and low hanging branches.

AWARNING

Severe injury or death can result if your vehicle comes in contact are immediately visible.

Travel with caution in unfamiliar terrain.



Driving in Reverse

Follow these precautions when operating in reverse:

- 1. Always avoid backing downhill.
- 2. Back slowly.
- 3. When in reverse, apply the brakes lightly for stopping.
- 4. Avoid turning at sharp angles in reverse.
- 5. Never open the throttle suddenly while backing.




AWARNING

Failure to use caution when operating in reverse can result in serious injury or death. Before shifting into reverse, always check for obstacles or people behind the vehicle. When it's safe to proceed, back slowly. Do not use the override switch unless additional power is required for vehicle movement. Use with caution. Avoid backing on inclines, and avoid turning at sharp angles.

NOTE

Your Tractor is equipped with a reverse speed limiter. The override button should be used with caution as rearward vehicle speed is greatly increased. Do not operate at wide open throttle. Open the throttle just enough to maintain a desired speed.




AWARNING

Excessive throttle operation while in the speed limit mode may cause fuel to build in the exhaust, resulting in engine popping and/or engine damage. Engine brake will be executed and rear output shaft locked when gear on the parking position.

Parking on an Incline

Avoid parking on an incline if possible. If it s unavoidable, follow these:

- 1. Turn the engine off.
- 2. Place the gear selector to parking position.
- 3. Always block the rear wheels on the downhill side as illustrated.



TURNING YOUR TRACTOR

To achieve maximum traction while riding in 2WD or 4WD, the two rear wheels are mounted solidly on one axle and turn together at the same speed. Furthermore, when riding in 4WD-LOCK (DIFF. LOCK), the front wheels also turn together at the same speed. Therefore, unless the wheel on the inside of the turn is allowed to slip or lose some traction, the Tractor will resist turning. A special turning technique must be used to allow the Tractor to make turns quickly and easily. It is essential that this skill be learned first at low speed.

AWARNING


Always follow proper procedures for turning as described in this Owner's Manual. Practice turning at low speeds before attempting to turn at faster speeds. Do not turn at speeds too fast for your skills or the conditions. Operate at a slow speed and allow extra time and distance for maneuvers when in 4WD-LOCK (DIFF. LOCK).

As you approach a curve, slow down and begin to turn the handlebars in the desired direction. As you do so, put your weight on the footboard to the outside of the turn (opposite your desired direction) and lean your upper body into the turn. Use the throttle to maintain an even speed through the turn. This maneuver will let the wheel on the inside of the turn slip slightly, allowing the Tractor to make the turn properly.

This procedure should be practiced at slow speed many times in a large area with no obstacles. If an incorrect technique is used, your tRACTOR may continue to go straight. If the Tractor doesn't turn, come to a stop and then practice the procedure again. If the riding surface is slippery or loose, it may help to position more of your weight over the front wheels by moving forward on the seat. Once you have learned this technique you should be able to perform it at higher speeds or in tighter curves. Improper

riding procedures such as abrupt throttle changes, excessive braking, incorrect body movements, or too much speed for the sharpness of the turn may cause the Tractor to tip. If the Tractor begins to tip over to the outside while negotiating a turn, lean more to the inside. It may also be necessary to gradually let off on the throttle and steer to the outside of the turn to avoid tipping over.

Remember: Avoid higher speeds until you are thoroughly familiar with the operation of your Tractor.



Accessories

Auxiliary power outlets provide 12V power for operating accessories such as hand held spot light s. Please consult with your dealer.

Periodic maintenance chart

Following the maintenance schedule in your owner's manual will help keep your vehicle in the safest, most reliable condition. Inspection, adjustment, and lubrication of important components are explained in the maintenance schedules.

Inspect, clean, lubricate, adjust, and replace parts as necessary. When inspection reveals the need for replacement parts, please use genuine parts available from your dealer.

Severe Use De inition

CFMOTO defines severe vehicle use as:

- · Frequent immersion in mud, water or sand
- · Racing or race-style high RPM use
- · Prolonged low speed, heavy load operation
- · Extended engine idle
- Short trip, cold weather operation
- · Vehicles used in commercial operations

For vehicles that are subjected to severe use, reduce all maintenance and service intervals by 50%.

NOTE

Periodic service and adjustments are critical. If you are not familiar with performing safe service and adjustment procedures, have a qualified dealer perform the required maintenance for you.

NOTE

Pay special attention to the engine oil level during cold weather operation. A rise in engine oil level can indicate contaminants collecting in the oil sump or crankcase. Change oil immediately if the oil level begins to rise. Monitor the oil level, and if it continues to rise, discontinue use and determine the cause, or see your dealer.

Periodic Maintenance Schedule and Icon Key

Maintenance intervals in the following schedules are based upon average riding conditions and an average operating speed of approximately 12.4 mph (20 km/h). Vehicles subjected to severe or commercial use must be inspected and serviced more frequently.

The following icon keys are used to note special circumstances:

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

△WARNING

Procedures marked as '∎' means if repair is required, have an authorized dealer perform repairs that involve this component or system. Improperly performing the procedure could result in component failure and lead to serious injury or death.

KEY POINTS OF LUBRICATION SCHEDULE:

Check all components at the intervals outlined in the Periodic Maintenance Schedule. Items not listed in the schedule should be lubricated at the general lubrication interval.

- Change lubricants more often under severe use, such as wet or dusty conditions.
- · Use All Season Grease on pivot points.
- Lubricate every 500 miles (800 km), before long periods of storage, after pressure washing, or after submerging drive system.

Item	Lubricant	Method	
Engine oil	SAE 5W-40 Minimum SG rated	Screw off, clean, insert and pull out dipstick to check oil level	
Brake fluid	DOT4	Keep level between upper and lower lines	
Front gear case oil	SAE80W-90 GL-5	Oil capacity: 7.8 oz. (230mL)	
Rear gear case oil	SAE80W-90 GL-5	Oil capacity: 8.5 oz. (250mL)	
Suspension pivots and drive train	All Season Grease	Grease gun - Pump grease until it begins to flow from the pivot point	

Pre-Ride Maintenance Checklist

Perform these inspections before operating the vehicle:

	140.00		Maintena	nce before o	peration
	Item		Calendar	Miles (km)	Remarks
	Steering system	-	Pre-Ride	-	
	Throttle return	-	Pre-Ride	-	
	Front suspension and axles	-	Pre-Ride	-],, , , , , , ,
	Rear suspension and axles	-	Pre-Ride	-	Visually inspect, test,
	Tires	-	Pre-Ride	-	or check components. Make adjustments and/
	Brake fluid level	-	Pre-Ride	-	or schedule repairs
	Brake lever / foot brake function	-	Pre-Ride	-	when required.
	Brake system function	-	Pre-Ride	-	Wilch required.
	Wheels / fasteners	-	Pre-Ride	-	
	Engine oil level	-	Pre-Ride	-]
•	Air filter / Air box and connections	-	Pre-Ride	-	Visually inspect. Replace filter when dirty.

- ▶ = Severe Use Item. Inspect frequently on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this componen or system.

	14		Maintena	nce before o	peration
	Item	Hour	Calendar	Miles (km)	Remarks
•	Air box sediment tube	-	Pre-Ride	-	Inspect. If deposits are visible, clean intake tubes, air box, and replace air filter.
•	CVT sediment tube	-	Pre-Ride	-	Inspect. If deposits are visible, drain / clean the CVT or have it serviced by a dealer.
-	Headlight aim / General lighting and turn indicators (if equipped)	ı	Pre-Ride	-	Inspect. Adjust or replace lights when necessary.
•	Radiator	-	Pre-Ride	-	Inspect for mud or debris blocking airflow. Clean surfaces when necessary.

- ► = Severe Use Item. Inspect frequently on vehicles subjected to severe us
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

Break-In Maintenance Checklist

Perform these maintenance items when the 20-hour vehicle break-in is completed:

	ltem		Break-in Maintenance (Perform at the interval that arrives first)			
		Hour	Calendar	Miles (km)	Remarks	
	General lubrication	20	-	200 (320)	Lubricate all grease points, pivots, cables, etc.	
	Engine oil / oil filter / oil strainer	20	-	200 (320)	Change oil and filter. Clean oil strainer.	
•	Engine air filter	20	-	200 (320)	Inspect; replace if dirty; do not clean	
•	Engine valve clearance	20	-	200 (320)	Check and adjust as necessary.	
	Front / Rear gear case oil	20	-	200 (320)	Check level. Inspect for leaks.	
	Coolant	20	-	200 (320)	Check level. Inspect for leaks.	
•	Brake pads	20	-	200 (320)	Inspect pad thickness.	

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use.
- = Have an authorized dealer perform repairs that involve this component or system.
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

	ltem		Break-in Maintenance (Perform at the interval that arrives first)				
			Calendar	Miles (km)	Remarks		
	Battery	20	-	200 (320)	Check terminals, clean, test battery condition if required.		
•	Idle condition	20	-	200 (320)	Inspect for proper rpm. See dealer for service if out of spec or erratic.		
•	Steering / Wheel Alignment	20	-	200 (320)	Inspect steering system. See dealer for service if wheel alignment is required.		
•	Foot brake / Hand brake	20	-	200 (320)	Inspect function. Adjust as necessary.		
	Gear cases, CV shafts, Propshafts	20	-	200 (320)	Inspect for leaks.		
	Engine hoses, gaskets and seals	20	-	200 (320)	Inspect for leaks.		

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

Periodic Maintenance Schedule

Perform maintenance at the interval that arrives first after the 20-hour break-in period:

Item		Periodic Maintenance Intervals (Perform at the interval that arrives first)				
		Hour	Calendar	Miles (km)	Remarks	
•	Brake pads	10	Monthly	100 (160)	Inspect pad thickness.	
	Battery	20		200 (320)	Check terminals. Clean and test battery condition as necessary.	
	Engine hoses, gaskets and seals	20	-	200 (320)	Inspect for leaks.	
•	Air filter	50h		500 (800)	Always inspect pre- ride. Inspect frequently if subjected to severe use. Replace if dirty. Do not clean.	
•	General lubrication	50h	3M	500 (800)	Lubricate all grease points, pivots, cables, etc.	

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use.
- = Have an authorized dealer perform repairs that involve this component or system.
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

	ltem		Periodic Maintenance Intervals (Perform at the interval that arrives first)				
		Hour	Calendar	Miles (km)	Remarks		
•	Front gear case oil	50h	12M	500 (800)	Inspect level. Change yearly if hours or distance interval is not met.		
•	Rear gear case oil	50h	12M	500 (800)	Inspect level. Change yearly if hours or distance interval is not met		
•	Engine oil / oil filter / oil strainer	100h	12M	1000 (1600)	Inspect for color change. Change if dirty and clean strainer. Change yearly if hours or distance interval is not met.		
	Cooling system	50h	6M	500 (800)	Test coolant strength. Pressure test system yearly.		

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

	Item	Periodic Maintenance Intervals (Perform at the interval that arrives first)			
		Hour	Calendar	Miles (km)	Remarks
•	Radiator	50h	6M	500 (800)	Inspect; clean external surfaces. Clean more frequently if subjected to severe use.
	Steering system	50h	6M	500 (800)	Inspect. Lubricate.
•	Front suspension	50h	6M	500 (800)	Lubricate. Check fasteners.
•	Rear suspension	50h	6M	500 (800)	Lubricate. Check fasteners.
•	Gear shift	50h	1M	500 (800)	Inspect, lubricate, adjust as necessary.
>	Throttle body / throttle cable	50h	6M	500 (800)	Inspect. Clean carbon deposits. Inspect cable and lubricate frequently if subjected to severe use.

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

Item		Periodic Maintenance Intervals (Perform at the interval that arrives first)				
		Hour	Calendar	Miles (km)	Remarks	
•	CVT drive belt	50h	12M	1500 (2400)	Inspect. Replace as necessary. See dealer for service.	
•	CVT drive and driven pulleys	100h	12M	500 (800)	Clean and Inspect pulleys. Replace worn parts. See dealer for service.	
	Fuel filter and hoses	100h	24M	2000 (3200)	Inspect routing and condition. Replace filter and high-pressure hoses every 4 years.	
	Cooling hoses	100h		1000 (1600)	Inspect routing and condition.	
•	Valve clearance	100h		2000 (3200)	Inspect and adjust as necessary. See dealer for service.	

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

	Item		Periodic Maintenance Intervals (Perform at the interval that arrives first)			
			Calendar	Miles (km)	Remarks	
•	Fuel system	100h	12M	500 (800)	Inspect fuel tank, cap, fuel pump and fuel pump relay.	
	Spark plug	100h	24M	2000 (3200)	Inspect; Replace if worn or fouled.	
•	Engine mounts	100h	12M	1500 (2400)	Inspect condition.	
	Exhaust pipe and spark arrestor	100h	12M	500 (800)	Inspect. Clean spark arrestor.	
•	Wiring, fuses, connectors, relays, and cables	100h	12M	1000 (1600)	Inspect wire routing for wear, security. Apply dielectric grease as necessary to connectors subjected to water, mud, etc.	

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

ltem		Periodic Maintenance Intervals (Perform at the interval that arrives first)			
		Hour	Calendar	Miles (km)	Remarks
> •	Wheel bearings	100h	12M	1500 (2400)	Inspect for noise or looseness Replace as necessary.
•	Safety Belts	100h	12M	2000 (3200)	Visually inspect belts and test latches. Clean latch mechanism more often if used in severe conditions.
	Coolant	200h	24M	4000 (6400)	Change coolant every 2 years if hours or distance interval is not met.
•	Brake fluid	200h	24M	1000 (1600)	Inspect fluid for color change. Change fluid every two years.

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

Item		Periodic Maintenance Intervals (Perform at the interval that arrives first)			
		Hour	Calendar	Miles (km)	Remarks
	Idle condition		12M		Inspect for proper rpm. See dealer for service if out of spec or erratic.
•	Steering / Wheel Alignment		12M		Inspect steering system. See dealer for service whenever steering parts or wheel alignment are required.
•	Foot brake height		12M		Inspect. Replace brake pads or adjust height as required.

- ▶ = Severe Use Item. Reduce interval by 50% on vehicles subjected to severe use
- = Have an authorized dealer perform repairs that involve this component or system
- = Emissions related components. Have an authorized dealer perform repairs that involve this component or system.

Maintenance & Lubrication Lubrication recommendations

Engine oil

Always check and change the engine oil at the intervals outlined in the Periodic Maintenance Chart beginning on page 99 and 100. Always change the oil filter whenever changing oil.


Engine oil check


- 1. Remove plastic cover ① as right picture shows.
- 2. Position the Tractor on a level surface.
- 3. Start the engine and let it idle for 20~30 seconds. Stop the engine.
- 4. Wait a few minutes until the oil settles.
- 5. Take oil dipstick out from 1 and wipe off area 2 of dipstick with a clean rag.
- 6. Insert the dipstick in the oil filler hole, no need to screw it in, then remove it again to check the oil level.

NOTE

The engine oil should be between the upper and lower limit marks.








Engine oil check

- 7. If the engine oil is at or below the lower limit mark, add sufficient oil of the recommended type to raise it to the correct level.
- 8. Insert the dipstick into the oil filler hole, and then tighten it.
- 9. Install plastic cover ① .

To change engine oil

- 1. Start the engine, warm it up for $(2\sim3)$ minutes, and then stop the engine.
- 2. Place an oil pan under the engine to collect the used oil.
- 3. Remove the engine oil drain bolt 1 to drain the oil from the crankcase.
- 4. Remove the bolt 2 and filter cover 3, remove the filter, wash it and install again.



Oil filter replacement

1. Use wrench to unscrew 3 pcs of bolts ${\scriptsize \textcircled{\scriptsize 1}}$ as right picture shows.

Then remove cover ② of oil filter and remove oil filter ③.

2. Install new oil filter on it.

Attention: Confirm if O-ring ④ is good and then install it into groove of crankcase correctively.

- 3. Install new oil filter ③, and use wrench to tighten 3 pcs of bolts
- ① on cover ②by specified torque.

NOTE: Tightening torque of bolt ①: 10 N • m


4. Use new washer to assemble and tighten oil drain bolt as specified torque.

NOTE: Tightening torque of drain bolt: 30 N • m


5. Add the specified amount of recommended engine oil, and then insert the engine oil dipstick and tighten it.


NOTE

In case of engine overhaul, oil should be added: 3.0 L; Without oil filter cartridge replacement, oil should be added: 2.8 L With oil filter cartridge replacement, oil should be added: 2.9L



7. Turn the engine off, and then check the oil level and correct it if necessary.





Maintenance & Lubrication Rear gear case oil

The rear gear case must be checked for oil leakage before each ride. If any leakage is found, have your dealer check and repair the Tractor.

Rear gear oil change

- 1. Place the machine on a level place.
- 2. Place a container under the rear gear case to collect the used oil.
- 3. Remove the filler bolt 1 and the drain bolt 2 as right picture shows and drain used oil.
- 4. Install and tighten drain bolt ② as specified torque, after adding new gear oil into rear gear case, lastly Install the filler bolt ① as specified torque.



Tightening torque of drain bolt: 23N • m

NOTE

Periodic oil change: 0.25 L

Oil capacity of rear gear case: 0.30 L





5. Check if any oil leakage. In case of leakage, please find causes and remove it.

Attention: Be sure no foreign material enters the rear gear case.

Front gear case oil measurement


- 1. Place the machine on a level place.
- 2. Remove the oil filler bolt ② and check the oil level. It should be up to the brim of the hole. If the level is low, add sufficient oil to raise it to the specified level.
- 3. Install the oil filler bolt and tighten it to the specified torque.

NOTE

Oil filler bolt tightening torque: 23 N • m

Front gear case oil change

- 1. Place the machine on a level place.
- 2. Place a container under the front gear case to catch the oil.
- 3. Remove oil filler bolt and drain bolt 1 at the bottom of front gear case, and drain used oil.



Maintenance & Lubrication Front gear case oil change

4. Install the drain bolt and tighten it to the specified torque.

NOTE

Drain bolt tightening torque: 10 N • m

5. Fill the front gear case with oil.

NOTE

Periodic oil change: 0.28 L


Oil capacity: 0.33 L

6. Install the filler bolt ② as page 102 shows and tighten it to the specified torque.

7. Check for oil leakage. If oil leakage is found, check for the cause.

NOTE

Be sure no foreign material enters the front gear case.





Cooling system

- 1. Place the Tractor on a level surface.
- 2. Check the coolant level in the coolant reservoir when the engine is cold as the coolant level will vary with engine temperature.

NOTE

The coolant should be between the upper and lower limit marks.

Cooling system

3. If the coolant is at or below the lower limit mark, remove the reservoir cap①, add coolant to the upper limit mark, install the reservoir cap, and then install the panel.

NOTE

Lowest capacity of coolant reservoir: 0.23 L

CAUTION

Hard water or salt water is harmful to the engine. You may use soft water if you can not get distilled water.

A Attention

If water is added, have your dealer check the antifreeze content of the coolant as soon as possible. The radiator fan operation is completely automatic. It is switched on or off according to the coolant temperature in the radiator


Maintenance & Lubrication Changing the coolant

- 1. Place the Tractor on a level ground.
- 2. Place a container under the engine, and then remove (engine Left cover①、smaller engine left cover②) the coolant drain bolt③.
- 3. Remove the radiator cap 5.
- 4. Remove the coolant reservoir cap4.

A DANGER

After stop the engine, you cannot remove cap of radiator immediately. Wait for a while to cool down the coolant and then remove radiator cap. Otherwise hot coolant will goes out to hurt people nearby.

- 5. Disconnect the hose on the coolant reservoir side, and then drain the coolant from the coolant reservoir.
- 6. After draining the coolant, thoroughly flush the cooling system with clean tap water.
- 7. Replace the coolant drain bolt washer if it is damaged, and then tighten the coolant drain bolt to the specified torque.



NOTE

Coolant drain bolt tightening torque: 10 N • m

- 8. Install the coolant reservoir hose.
- 9. Fill the recommended coolant into the radiator until it is full.

When filling coolant, at the same time to loosen tapping screw as right picture ③ shows in order to drain potential air bubbles inside the coolant hose, until coolant goes out, then tighten the screw.



NOTE

Recommended antifreeze:

High quality ethylene glycol antifreeze containing corrosion inhibitors

for aluminum engines. Antifreeze and water mixing ratio:1:1

Coolant capacity: 2.0 L. Coolant change: 1.9 L.

Coolant reservoir capacity: 0.23L ~0.41L

CAUTION

Hard water or salt water is harmful to the engine.

Please use CFMOTO recommended coolant.

- 10. Install the radiator cap.
- 11. Start the engine and let it idle for several minutes. Stop the engine, and then check the coolant level in the radiator. If it is low, add more coolant until it reaches the top of the radiator.
- 12. Fill the coolant reservoir with coolant up to the upper limit.
- 13. Install the coolant reservoir cap and check for coolant leakage.


NOTE


If any leakage is found, have your dealer check the cooling system.

14. Install the panels and the front rack.

Axle dust boots

Check the protective boots for holes or wears. If any damage is found, have them replaced by your dealer.






Spark plug inspection

Removal

- 1. Remove the panel.
- 2. Remove the spark plug cap①.
- 3. Use the spark plug wrench in the tool kit to remove the spark plug as shown.



Maintenance & Lubrication Inspection


The spark plug is an important engine component and is easy to inspect. The condition of the spark plug can indicate the condition of the engine. The ideal color on the white insulator around the center electrode is a medium-to-light tan color for a Tractor that is being ridden normally. Do not attempt to diagnose such problems yourself. Instead, take the Tractor to your dealer. You should periodically remove and inspect the spark plug because heat and deposits will cause the spark plug to slowly break down and erode. If electrode erosion becomes excessive, or if carbon and other deposits are excessive, you should replace the spark plug with the specified plug.




Measure the electrode gap with a wire thickness gauge and, if necessary, adjust the gap to specifications.

NOTE: 1.Spark plug gap: 0.8mm~0.9mm

- 2. Clean the gasket surface. Wipe off any grime from the threads.
- 3. Install spark plug and tighten to specified torque. –1 20–





NOTE: Tightening torque of spark plug: 20N · m


If a torque wrench is not available when you are installing a spark plug, a good estimate of the correct torque is 1/4 to 1/2 turn past finger tight. Have the spark plug tightened to the specified torque as soon as possible.

- 4. Install the spark plug cap.
- 5. Install the panel.

Air filter element cleaning

There is a check hose ① at the bottom of the air filter case. If dust or water collects in this hose, empty the hose and clean the air filter element and air filter case. If there's a lot for water, please contact your local dealer to check if any water inside crankcase.

- 1. Remove seat and disassemble cover of air filter.
- 2. Remove spring ① and remove upper cover of air filter ②.
- 3. Remove bolt of pipe clamp^③.
- 4. Remove air filter element 4.
- 5. Remove polyurethane foam of filter element, Wash the air filter element gently but thoroughly in solvent. Squeeze the excess solvent out of the air filter element and let it dry.




- 6. Softly clean dust on filter element.
- 7. If necessary, use new filter element to replace.

CAUTION

Don't use liquid to wash paper filter element.

- 8. Inspect the air filter element and replace it if damaged.
- 9. Install air filter element and connect to hose.
- 10. Install the air filter case cover and be sure to seal ring installed well.



NOTE

The air filter element should be cleaned every 50 hours, It should be cleaned and lubricate more often if the machine is operated in extremely dusty areas. Each time air filter element maintenance is performed, check the air inlet to the air filter box for obstructions. Check the air filter element rubber joint to the throttle body and manifold fittings for an airtight seal. Tighten all fittings securely to avoid the possibility of unfiltered air entering the engine.


A DANGER


Do not start engine without air filter element. Not filtered air will entre into the engine and cause engine wearing and damage. In addition, driving without air filter will also decrease performance and engine overheating.

Clean spark arrester:

Clean spark arrester while muffler and exhaust are in normal temperature.

- 1. Remove bolts ①。
- 2. Remove spark arrester ② from muffler;
- 3. Tap the tailpipe lightly, and then use a wire brush to remove any carbon deposits ③ from the spark arrester portion of the tailpipe.
- 4. Insert the tailpipe into the muffler and align the bolt holes;
- 5. Install and tighten the bolts ①.





A DANGER

When cleaning the spark arrester: Always let the exhaust system cool prior to touching exhaust components. Do not start the engine when cleaning the exhaust system.

CVT air-outlet hose cleaning

If dust or water collects in the V-belt cooling duct check. hose, remove the hose ① and clean it.


CVT cover drain bolt

After riding in water deep enough to allow it to enter the V-belt case, remove this bolt ② to drain the water from the case

WARNING

f water drains from the V-belt case after removing the bolt, have your dealer inspect the Tractor as the water may affect other engine parts.





Throttle body adjustment

The throttle body is a vital part of the engine and requires very sophisticated adjustment. Most adjusting should be left to your dealer who has the professional knowledge and experience to do so. However, the idling speed may be performed by the owner as a part of the usual maintenance routine. The throttle body was set at the factory after many tests. If the settings are disturbed by someone without sufficient technical knowledge, poor engine performance and damage may result. Check idle for stability and contact your dealer for service if necessary.

Engine idel adjustment:

AWARNING

this vehicle is equipment with EFI system, and no need to adjust idle, or performance will be affected. Contact your dealer in case abnormal idle.

NOTE

Engine idle: 1,500r/min ± 100r/min (Heated engine)

• Engine airinlet/outlet valve clearance adjustment

The correct valve clearance changes with use, resulting in improper fuel/air supply or engine noise. To prevent this, the valve clearance must be adjusted regularly. This adjustment however, should be left to a professional service technician.

NOTE

Adjust the engine idling speed before Adjusting the throttle lever free play on Page 120.

- 1. Loosen nut ①.
- 2. Turn adjustment nut ② to lever travel:
 - ⓐ: 3mm~5 mm.
- 3. Fasten nut (1).


• Front brake pad check

Inspect the brake pads and brake disks for damage and wear. If the thickness "a" is less than 1.5mm or "b" is less than 3.0mm,then have your dealer replace them..

NOTE

Front wheels need to be removed to check brake pads ①







Rear brake pad inspection

Inspect the brake pads and brake disks for damage and wear. If the thickness "a" is less than 1.5mm or "b" is less than 4.0mm. then have your dealer replace them.

Inspect brake fluid level

Insufficient brake fluid may let air enter the brake system, possibly causing the brakes to become ineffective. Before riding, check that the brake fluid is above the lower level and replenish when necessary. The front brake fluid master cylinder reservoir is located







• Inspect brake fluid level

Observe these precautions:

- 1. When checking the fluid level, make sure the top of the master cylinder reservoir is level by turning the handlebars.
- 2. Use only the designated quality brake fluid. Otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.

NOTE

Recommended brake fluid: DOT3 or DOT 4.

- 3. Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor brake performance.
- 4. Be careful that water does not enter the master cylinder reservoir when refilling. Water will significantly

lower the boiling point of the fluid and may result in vapor lock.

- 5. Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- 6. Have your dealer check the cause if the brake fluid level goes down.

• Brake fluid change

Complete fluid replacement should be done only by trained service personnel. Have your dealer replace the following components during periodic maintenance or when they are damaged or leaking.

- •Replace the oil seals every two years;
- •Replace the brake hoses every four years.



The front brake lever should have a free play of zero mm (zero in) at the lever end. If not, have your dealer check the brake system.

a

▲ DANGER(After servicing):

- Make sure the brakes operate smoothly and that the free play is correct;
- •Make sure the brakes do not drag. Make sure the brakes are not spongy.
- •All air must be bled from the brake system. Replacement of brake components requires professional knowledge. These procedures should be performed by your dealer.

▲ DANGER(After servicing):

- Make sure the brakes operate smoothly and that the free play is correct;
- •Make sure the brakes do not drag. Make sure the brakes are not spongy.
- •All air must be bled from the brake system. Replacement of brake components requires professional knowledge. These procedures should be performed by your dealer.

• Rear brake padal hight adjustment

NOTE

Adjust the rear brake before inspecting the rear brake pads.

The top of the brake pedal should be positioned 70mm ~ 80mm above the top of the footrest. If not, ask your dealer to adjust it.

A DANGER

After servicing:

- •Make sure the brakes operate smoothly and that the free play is correct.
- •Make sure the brakes do not drag;
- •All air must be bled from the brake system.

Replacement of brake components requires professional knowledge. These procedures should be performed by your dealer.



• Rear brake light switch

The rear brake light switch, which is activated by the brake pedal and brake levers, is properly adjusted when the brake light comes on just before braking takes effect.

• Rear brake light switch

Check switch assembly or cable is properly fixed in case light failure.

Cable inspection and lubrication

A DANGER

Inspect cables frequently. Replace damaged cables. Lubricate the inner cables and the cable ends. If the cables do not operate smoothly, ask your dealer to replace them.

NOTE


Recommended Jubricant: SAE 10W30

Rear knockle upper and lower pivot Lubrication:

Lubricate the upper and lower shaft of the rear axle Remove the rear wheel 1, Add oil into the oil cup 2 between the upper and lower axle with spray gun.

NOTE

Recommend lubrication: lithium base grease



ANOTE

Recommended lubricant: Lithium-soap-based grease

Wheel removal

- 1. Loosen the wheel nuts.
- 2. Elevate the ATV and place a suitable stand under the frame.
- 3. Remove the nuts from the wheel.
- 4. Remove the wheel.

Wheel installation:

1. Install the wheel and the nuts.

NOTE


- •Tapered nuts are used for both the front and rear wheels. Install the nut with its tapered side towards the wheel
- •The arrow mark on the tire must point toward the rotating direction of the wheel.

- 2. Lower the Tractor so that the wheel is on the ground.
- 3. Tighten the wheel nuts to the specified torque.

NOTE

Wheel nut torque: Front: 70 N·m~80 N·m

Rear: 70 N·m~80 N·m



Battery

This machine is equipped with service-needless battery. Therefore it is not necessary to check the electrolyte or add distilled water in the battery. If the battery seems to have discharged, consult your dealer.

NOTE

Battery specification: 12V 30Ah

AWARNING

Do not try to remove the sealing caps of the battery cells. You may damage the battery.

A DANGER

Avoid contact with skin, eyes or clothing. Always shield eyes when working near batteries. Keep out of reach of children.

Antidote:

EXTERNAL: Flush with water. INTERNAL: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Get prompt medical attention.

EYES: Flush with water for 15 minutes and get prompt medical attention. Keep batteries away from sparks, flames, cigarettes or other sources of ignition. Ventilate when charging or using in a closed space.

Battery maintenance:

- 1. When the machine is not used for a month or longer, remove the battery and store it in a cool, dark place. Completely recharge the battery before reinstallation.
- 2. A special battery charger (constant voltage/ampere or constant voltage) is required for recharging battery. Use a conventional battery charger may shorten the battery life.
- 3. Always make sure the connections are correct when putting the battery back in the machine.


• Fuse replacement

- 1. The main fuse ①, fuse box ② and relay box ③ are located under front top cover.
- 2. If a fuse is blown, turn off the main switch and install a new fuse of the specified amperage.

Then turn on the switches. If the fuse immediately blows again, consult your dealer.


Danger:


Always use a fuse of the specified rating. Never use a material in place of the proper fuse.




- 1. Headlight fuse 15A
- 2. Fan fuse 15A
- 3. Start relay fuse 15A
- 4. Signal, Fuel pump fuse 10A
- 5.null 6.Oxygen Sensor fuse(5A)
- (7). Spare fuse(15A/10A/5A)
- Flash









- 1. High-Tension Ignition coil 4. Fuse (20A)
- 2.Batterv
- 3.Idle Valve

- (5). Start Relay
- 6. FCU
- 7. Regulator/Rectifier

AWARNING

To prevent accidental short-circuit, turn off the main switch when checking or replacing a fuse.

Headlight adjustment/ Lamp replacement:

Remov e the two screws 2 and plastic clamp 3, remov e the headlight panel 1, you can adjust, remove ,install and replace it.

Beam adjustment:

Switch the adjust screws 4, adjust the high or low direction of the high beam 8.


Switch the two adjust screws ⑤, adjust the high or low direction of the low beam ⑦ vertically and horizontally.

Lamp replacement 6:

- 1.Remove the connectors in the lamp, hold the lamp holder and turn it to 60 degree anticlockwise.
- 2. Reverse the above steps to install the new lamp.


Lamp Size: HB3 12V 60W





AWARNING

Touch the lamp only after it has been cooled down. Low-beam light 1 ,position light 2, high-beam light 3 and front turning light 4 are all the LED whole structure, which can't be fixed if there is any damage, only can be replaced.



• Headlight beam adjustment

AWARNING

It is advisable to have your dealer make this adjustment. **Taillight Replacement**:


The taillight is is the LED whole structure, which can't be fixed if there is any damage, only can be replaced.

- 2. Remove the four screws ① to remove the defected or damaged taillight.
- 3. Replace the new taillight reverse the step (1).

License plate lamp

If the License plate lamp is damaged, pull out the lamp holder from the rear of the License plate lamp to replace it.

Specification: 12V 5W W5W



• Front and rear suspension adjustment


The spring preload can be adjusted to suit the rider's weight and riding conditions.

Standard shock absorbers

NOTE

When adjusting the rear shock absorbers, the rear wheels need to be removed. adjust the spring preload as follows.

To increase the spring preload, turn the adjusting ring in Direction (a).



To decrease the spring preload, turn the adjusting ring in Direction (b).

NOTE

A special wrench can be obtained at a dealer to make this adjustment.


Standard position: B

A-Minimum (soft)

E- Maximum (hard)

A DANGER

Always adjust the shock absorbers on the left and right side to the same setting.



Maintenance & Lubrication Vehicle immersion

AWARNING

If your vehicle becomes immersed, major engine damage can result if the machine is not thoroughly inspected. Take the vehicle to your dealer before starting the engine. For example, if engine is not properly handled after immersion, starting will damage the engine.

Clean & Storage

Cleaning the Tractor

Keeping your Tractor clean will not only improve its appearance but it can also extend the life of various components. With a few precautions, your Tractor can be cleaned much like an automobile.

Washing the Tractor

The best and safest way to clean your Tractor is with a garden hose and a pail of mild soap and water. Use a professional type washing mitten, cleaning the upper body first and the lower parts last. Rinse with water frequently and dry with a chamois to prevent water spots.

NOTE

If warning and safety labels are damaged, contact your dealer for replacement.

We do not recommend the use of a high pressure type car wash system for washing your Tractor. If a high pressure system is used, exercise extreme care to avoid water damage to the wheel bearings, transmission seals, body panels, brakes, warning labels, air filter intake system and electric system, etc. Water is not allowed to enter into air filter.

NOTE

Grease all zerk fittings immediately after washing, and allow the vehicle to run for a while to evaporate any water that may have entered the engine or exhaust system.

Clean & Storage

Waxing the Tractor

Your Tractor can be waxed with any non-abrasive automotive paste wax. Avoid the use of harsh cleaners since they can scratch the body finish.

CAUTION

Certain products, including insect repellants and chemicals, will damage plastic surfaces. Use caution when using these products near plastic surfaces.

CAUTION

Starting the engine during the storage period will disturb the protective film created by fogging and damage could occur. Never start the engine during the storage period.

Clean the Exterior

Make necessary repairs and then clean the Tractor thoroughly with mild soap and warm water to remove all dirt and grime. Do not use harsh detergents or high pressure washers. Some dete-rgents deteriorate rubber parts. Use dish soap type cleaners only. High pressure washers may force water past seals.

Oil and Filter

Warm the engine, then stop the engine and change the oil and filter.

CAUTION

When drain out fuel in fuel pipe and air pipe, if dashboard says only one grid of fuel left, remove fuel pump connector to drain out fuel in fuel tank, or else, it may damage fuel pump.

Air Filter/ Air Box

Inspect and clean or replace air filter. Clean the air box and drain the sediment tube.

Fluid Levels

Inspect the following levels and change if necessary: front gear case, rear gear case, engine oil, brake fluid (change every two years or as required if fluid looks dark or contaminated), coolant.

Fog the Engine

Remove spark plug and add $15\,\text{mL} \sim 20\text{mL}$ SAE 15W-40/SG engine oil. To access the plug hole, use a section of clean hose and a small plastic squeeze bottle filled with the pre-measured amount of oil.

CAUTION

Do this carefully! If you miss the plug hole, oil will drain from the spark plug cavity, and appear to be an oil leak.

Remove plug cap and turn crankshaft to make engine run slowly. Oil will be forced in and around the piston, piston rings and coating the cylinder with a protective film of fresh oil.

If you choose not to use the above way, perform the following procedure:

- 1. Support the front end of the vehicle so the engine is level or tilted slightly rearward.
- 2. Remove the spark plug, rotate the piston to BDC and pour approximately 15mL \sim 20mL oil into cylinder.
- 3. Remove plug cap and turn crankshaft to make engine rotate slowly.
- 4. Turn engine several times to ensure the coverage of piston rings and cylinder walls.
- 5. Treat the fuel system with Carbon Clean.
- 6. If fuel system Carbon Clean is not used, fuel tank, fuel pipe and throttle body should be completely drained of gasoline. To eliminate any fuel remaining in the fuel pipe.

Lubricate

Inspect all cables and lubricate with Cable Lubricant. Follow lubrication guidelines in the maintenance section of the service manual to completely grease and lubricate the entire vehicle with All Season Grease.

Battery Storage

Remove battery from the vehicle and ensure that it is fully charged before placing it in storage.

Engine Anti-Freeze

Test engine coolant strength and change if necessary. Coolant should be replaced every two years.

Storage Area/Covers

set the tires to specified air pressure and support the Tractor with tires $30 \, \text{mm} \sim 40 \, \text{mm}$ off the ground. Be sure the storage area s well ventilated and cover the machine with a Tractor cover.

ANOTE

Do not use plastic or coated materials. They do not allow enough ventilation to prevent condensation, and may promote corrosion and oxidation.

Transporting the Tractor

Tractor can not be transported with stand up position, follow these procedures when transporting the vehicle:

- 1. Turn off the engine and remove the key to prevent loss during transporting.
- 2.Place the gear into any position except Park position, block front and rear wheels to prevent Tractor run.
- 3. Never transport Tractor with gear in Park position, or else engine will be damaged.
- 4. Fix both the front and rear frame of Tractor at the same time, prevent Tractor slide or move during transportation.
- 5.Be sure the fuel cap, oil cap and seat are installed correctly.

Troubleshooting Drive belt and cover problems

Possible Cause	Solution
Driving the Tractor onto a pickup or tall trailer in high range.	Shift transmission to low range during loading of the Tractor to prevent belt burning.
Starting out going up a steep incline.	When starting out on an incline, use low range or dismount the Tractor (after first applying the park brake) and perform the K-turn as described on page 81.
Driving at low RPM or low ground speed(at approximately 5~10 km/h).	Drive at a higher speed or use low range more frequently. The use of low range is highly recommended for cooler CVT operating temperatures and longer component life.
Insufficient warm-up of Tractor exposed to low ambient temperatures.	Warm the engine before driving, the belt will become more flexible and prevent belt burning.
Slow and easy CVT engagement.	Use the throttle quickly and effectively for efficient engagement.
Towing/pushing at lowRPM/low ground speed.	Use low range only.
Utility use/plowing snow, dirt, etc.	Use low range only.

Troubleshooting

Possible Cause	Solution
Stuck in mud or snow.	Shift the transmission to low range, and carefully use fast, aggressive throttle application to engage CVT. WARRNING: Excessive throttle may cause loss of control and vehicle overturn.
Climbing over large objects from a stopped position.	Shift the transmission to low range, and carefully use fast, brief, aggressive throttle application to engage CVT. Excessive throttle may cause loss of control and vehicle overturn.
Belt slippage from water or snow ingestion into the CVT system.	Remove the CVT cover, drain the water from CVT.
CVT malfunction.	Contact your dealer for inspection of CVT components.

Troubleshooting Engine doesn't turn over

Possible Cause	Solution	
Poor engine performance.	Check for fouled plugs or foreign material in gas tank, fuel lines, or throttle. Contact your dealer for service.	
Tripped circuit breaker	Reset the breaker	
Low battery voltage	Recharge battery to 12.8 VDC	
Loose battery connections	Check all connections and tighten	
Loose solenoid connections	Check all connections and tighten	

Engine Pings or Knocks

Possible Cause	Solution
Poor quality or low octane fuel	Replace with recommended fuel
Incorrect ignition timing	See your dealer
correct spark plug gap or heat range	Set gap to specs or replace plugs

Troubleshooting EngineStops or loses power

Possible Cause	Solution
Overheated engine	Clean radiator screen and core if equipped Clean engine exterior See your dealer

Troubleshooting Engine Turns Over, Fails to Start

Possible Cause	Solution
Out of Fuel	Refuel
Clogged fuel valve or filter	Inspect and clean or replace
Water is present in fuel	Drain the fuel system and refuel
Fuel valve is out of use	Replace
Old or non-recommended fuel	Replace with new fuel
Fouled or defective spark plug(s)	Inspect plug(s), replace if necessary
No spark to spark plug	Inspect plug(s), verify stop switch is on
Crankcase filled with water or fuel	Immediately see your dealer
Overuse of choke	Inspect, clean and/or replace spark plugs
Clogged fuel injector	Clean or replace new fuel injector
Low battery voltage	Recharge battery to 12.8 VDC
Mechanical failure	See your dealer

Troubleshooting Engine Backfires

Possible Cause	Solution
Weak spark from spark plugs	Inspect, clean and/or replace spark plugs
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Old or non-recommended fuel	Replace with new fuel
Incorrectly installed spark plug wires	See your dealer
Incorrect ignition timing	See your dealer
Mechanical failure	See your dealer

Engine Runs Irregularly, Stalls or Misfires

Possible Cause	Solution
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs
Worn or defective spark plug wires	See your dealer
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Loose ignition connections	Check all connections and tighten
Water present in fuel	Replace with new fuel
Low battery voltage	Recharge battery to 12.8 VDC

Troubleshooting Engine Runs Irregularly, Stalls or Misfires

Possible Cause	Solution	
Kinked or plugged fuel vent line	Inspect and replace	
Incorrect fuel	Replace with recommended fuel	
Clogged air filter	Inspect and clean or replace	
Reverse speed limiter malfunction	See your dealer	
Electronic throttle control malfunction	See your dealer	
Other mechanical failure	See your dealer	
Possible Lean or Rich Fuel Mixture Cause	Solution	
Low or contaminated fuel	Add or change fuel, clean the fuel system	
Low octane fuel	Replace with recommended fuel	
Clogged fuel filter	Replace filter	
Incorrect jetting	See your dealer	
Overuse of choke	Inspect, clean and/or replace spark plugs	
Fuel is very high octane	Replace with lower octane fuel	

Troubleshooting Engine Stops or Loses Power

Possible Cause	Solution
Out of fuel	refuel
Kinked or plugged fuel vent line	Inspect and replace
Water present in fuel	Replace with new fuel
Overuse of choke	Inspect, clean and/or replace spark plugs
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs
Worn or defective spark plug wires	See your dealer
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Loose ignition connections	Check all connections and tighten
Low battery voltage	Recharge battery to 12.8 VDC
Clogged air filter	Inspect and clean or replace
Reverse speed limiter malfunction	See your dealer
Electronic throttle control malfunction	See your dealer
Other mechanical failure	See your dealer

Troubleshooting

EPS fault code table

Code	Diagnosis content	Suggestion
21	Main torque sensor disconnection	1.Check sensor wiring harness 2. Replace ECU
22	Main torque sensor output error(voltage is too high or low)	1.Check sensor wiring harness 2. Replace ECU
23	Vice torque sensor disconnected	1.Check sensor wiring harness 2. Replace ECU
24	Vice torque sensor output error(voltage is too high or low)	1.Check sensor wiring harness 2. Replace ECU
25	Main and vice torque difference is too large	1.Check sensor wiring harness 2. Replace ECU
26	Main torque sensor inner fault	Exchange ECU
35	Current sensor zero offset is too large	Re-insert wire of the motor
36	Motor disconnected	Exchange ECU
33	Current of ECU is over the limit	Exchange ECU
34	One side of motor has no assistance	Exchange ECU
32	Motor power-assistance abnormal	Check motor wire Check motor plu

EPS indicator on the Dashboard will be on when EPS system ① is equipped to the vehicle. Normally, EPS indicator will be on ② after ignition switch is turned to ON but EPS will not work. When the engine is started, EPS indicator will be off and EPS starts to function.

In case there is a failure, EPS indicator starts to flash. Do NOT switch off the machine. Check the flash times of EPS indicator. Write down the flash patterns and then refer to the Trouble Code Table for diagnosis.

Each trouble code consists of 2 digits, denoted by the times of long flash and short flash of EPS indicator.

Times of long flash represent the tens digit;

Times of short flash represent the single digit;

Duration of long flash: 2 sec.


Duration of short flash: 1 sec.

Flash interval: 1 sec.

The flash cycle will repeat after EPS indicator turns off for 3 seconds.

NOTE

In case of an EPS failure, do not disassemble the EPS system. Check the wiring for any loosening connection. Otherwise please contact an authorized dealer for service.



EPS fault diagnosis and solution

No.	Failure Phenomenon	Probable Reason	Troubleshooting
1	Steering without assistance	1. connectors of wire is bad contact 2. The fuse blew out 3. Relay damage 4. Thecontroller, motor or sensor is damaged	 Check whether wire connectors are fully inserted Replace the fuse (30A) Replace the relay Contact with suppliers and replace it
2	Power don't weighs the same for left and right	1. The median output voltage have deviation 2. controller, motor or sensor is damaged	1. Disconnect motor connectors, loosen the sensor adjustment screw, adjust the sensor position to keep the voltage in 1.65V ± 0.05V 2. Contact with suppliers and replace it
3	when system is on, the steering wheel swings on both sides	Motor is mounted backwards controller or sensor is damaged	1. Exchange the position of (thick line) red line and black line at the motor terminal 2. Contact with suppliers and replace it
4	Steering becomes heavy	1.Battery have power loss 2.Motor damage (power reduction) 3. air pressure of the tires (front) is insufficient.	 Charge Contact with suppliers and replace it Inflate tires
5	System has noise	1. Motor damage 2. Gap of lower steering shaft assembly or mechanical steering assembly is too large 3. Installation of lower steering shaft assembly or mechanical steering assembly is unfirm	1. Replace 2. Replace 3. Check whether the installation screw is tight, reinforcement

Itama	Specifications				
Items	CF400ATR-2S	CF500ATR-2S	CF400ATR-2L	CF500ATR-2L	
Overall Length	2180mm	2180mm	2380mm	2380mm	
Overall Width	1100mm	1100mm	1100mm	1100mm	
Overall Height	1150mm	1150mm	1350mm	1350mm	
Wheel Base	1260mm	1260mm	1460mm	1460mm	
Minimum ground clearance	250mm	250mm	250mm	250mm	
Min. turning radius	3500mm	3500mm	4000mm	4000mm	
Basic weight: (With engine oil and full fuel in tank)	358kg	358kg	382kg	382kg	
Engine model and type	191Q	191R	191Q	191R	
Туре	water-coolir	ng/4stroke, So	OHC		
Bore×Stroke	91mm×61.5mm	91mm×76.2mm	91mm×61.5mm	91mm×76.2mm	
Displacement	400mL	495mL	400mL	495mL	
Compression ratio	10.3:1	-	•		
Starting type	Electric start				
Lubrication type	Splashed by pressure				

Items		Specifications	
Engine oil:			
Type		SAE15W-40/SG	
Engine oil volume			
If change o	il filter	2.8 L	
If no change	e oil filter	2.9 L	
Rear Axle oil			
Туре		SAE80W/90 GL-5	
Volume		0.25 L	
Front axle oil:			
Туре		SAE80W/90 GL-5	
Volume		0.23 L	
Air filter		Dry-spongy filter element	
Maximum and	ТЗа	40km/h	
Maximum speed	T3b	60km/h	

Items			Parameters	
Fuel type			95(RON) or E10	
Fuel tank	capacity		15 L	
Fuel reve	rse amou	nt	3.0 L	
Spark plug:				
Type			DCPR8E (NGK)	
Spark plug	ggap		0.8mm~0.9mm	
	Clutch type		Wet and centrifugal automatic	
	Transmission Type		C(continuous variable transmission)(CVT)	
Transmission	Gear shift/order		Manually/L-H-N-R-P	
	Final	drive ratio	3.667	
	Gear	H gear	8.698~38.929	
	ratio	L gear	16.322~73.043	
R gear		R gear	13.344~59.721	
Chassis				
Frame			Steel tube	
Caster angle			3°	
Kingpin offset			27.97mm	

Items		Parameters	
Tire: Type		Tubeless	
Size	Front tire	25×8.0-12	
	Rear tire	25×10.0-12	
Tire pressure:			
Front tire		45kPa	
Rear tire		45kPa	
Brake system:		Front axes: Double-disc	
Unite brake	Type	Rear axes: Single-disc	
	Operation	Operated by right foot	
Front brake	Туре	Double-disc	
	Operation	Operated by right hand	
Rear brake	Туре	Single-disc	
	Operation	Operated by left hand	
Suspension:			
Front suspe	nsion	Double A-arm and independent	
Rear suspe	nsion	Double A-arm and independent	

Items	Parameters
Shock absorber: Front shock absorber Rear shock absorber	Coil spring/Oil damper Coil spring/Oil damper
Wheel travel: Front wheel travel Rear wheel travel	180 mm 180 mm
Electric system Ignition Flywheel storage battery	ECU A.C magneto 12V 30A
light system:	
Headlight type	LED
Front Turn light	LED
Front position light	LED
Rear Turn light	12V E10W 10W×2
Tail light/Brake light	LED
Registration board light	12V 5W W5W
Dashboard indicator light	LED

List of Tightening Moment of Force for Main Bolts, Screws, and Nuts STANDARD TORQUE VALUES

Item	Torque N • m	Item	Torque N • m
5mm bolt and nut	5	5mm screw	4
6mm bolt and nut	10	6mm screw	9
8mm bolt and nut	20~30	6mm screw,SH bolt	10
10mm bolt and nut	30~40	6mm flange bolt and nut	12
12mm bolt and nut	40~50	8mm flange bolt and nut	20~30
		10mm flange bolt and nut	30~40

FRONT CONSTANT VELOCITY JOINT

Item	Quantity	Thread dia (mm)	Torque N • m
Differential gear oil filler bolt	1	14	25
Differential gear oil drain bolt	1	14	25
Housing bolt	3	10	40~50

REAR CONSTANT VELOCITY JOINT

Item	Quantity	Thread dia (mm)	Torque N • m
Differential gear oil filler bolt	1	14	25
Differential gear oil drain bolt	1	14	25
Housing bolt	2	10	40~50

Winch safety precautions

↑WARNING

Moving Part Hazards

To prevent serious injury and property damage:

- Do not operate or install winch without reading and understanding these instructions and the Basic Guide to Winching Techniques.
- · Keep hands clear of wire rope, hook and fairlead opening during operation and when spooling.
- Use supplied hook strap for spooling wire rope.
- · Stand clear of wire rope and load during operation.
- Keep others away.
- · Inspect winch installation and wire rope condition before operating winch
- Do not use as a hoist.
- Do not use to move persons.
- · Do not exceed winch's rated capacity.
- Never touch wire rope or hook while in tension.
- Be certain the anchor you select will withstand load.
- Never wrap wire rope back onto itself. Use a choker chain or tree trunk protector on the anchor.
- Prior to initiating winching operation be sure any element which can interfere with safe winching is removed.
- Do not disengage clutch if winch is under load or wire rope is in tension.
- · Take your time. Sloppy rigging causes accidents.

↑CAUTION

To avoid injury and property damage:

- Do not use winch to secure a load during transport.
- · Do not submerge in water.
- · Do not use to tow other vehicles.
- Wear heavy leather gloves when handling the wire rope.
- Never winch with less than 5 wraps of wire rope around the drum.
- Caution should be used if the vehicle is tied down during a winching operation. This may lead to damage to the frame.
- Before winching, inspect remote control lead for damage.

Declaration of Drivers exposure to noise level

The undersigned: Lai Minjie, General Manager Company name and address of the manufacturer:

ZHEJIANG CFMOTO POWER CO., LTD.

No.116, Wuzhou Road, Yuhang Economic Development Zone, Hangzhou, 311100,

Zhejiang Province P.R.China

Make (trade name of the manufacturer): CFMOTO

Туре	Variant(s)	Version(s)	Commercial name(s) (if available)	Category, subcategory and speed index of the vehicle	The Drivers exposure to noise level result (limit:86dB(A))
	CF400ATR-2S	А	CFORCE450S	T3b	85.6 dB(A)
CF400ATR-2S	CF400ATR-2S	В	CFORCE450S	T3a	85.3 dB(A)
	CF500ATR-2S		CFORCE520S	T3b	85.7 dB(A)
	CF500ATR-2S	В	CFORCE520S	T3a	85.3 dB(A)
CF400ATR-2L	CF400ATR-2L	Α	CFORCE450L	T3b	85.6 dB(A)
	CF400ATR-2L	В	CFORCE450L	T3a	85.3 dB(A)
	CF500ATR-2L	А	CFORCE520L	T3b	85.7 dB(A)
	CF500ATR-2L	В	CFORCE520L	T3a	85.3 dB(A)

test method 2 of Annex XIII to EU 1322/2014.

Place: Hangzhou, China Date:10 Aug. 2016

Signature:

Name and position in the company: Lai Minjie, General Manager

Declaration of Vibration declaration

Driver m	ass	a_{ws} m/s ²	CF400ATR-2S/CF500ATR-2S	CF400ATR-2L/CF500ATR-2L	Requirement
	T1	Test run 1	1.23	1.22	Deviation<10%
59kg±1kg	T2	Test run 2	1.22	1.21	between test run 1/2
	Α	Arithmetic mean	1.23	1.22	and Arithmetic mean, a _{wS} <1.25 m/s ²
	T1	Test run 1	1.14	1.09	Deviation<10%
98kg±5kg	T2	Test run 2	1.13	1.10	between test run 1/2
	Α	Arithmetic mean	1.14	1.10	and Arithmetic mean, a _{wS} <1.25 m/s ²

a_{wS}:rms value of the weighted seat vibration acceleration measured during a standard roadway test

Place: Hangzhou, China

Date:10 Aug. 2016

Signature:

Name and position in the company: Lai Minjie, General Manager

LIMITED WARRANTY

ZHEJIANG CFMOTO POWER CO., LTD gives a limited warranty on all components of your CFMOTO **ATV** against defects in material or workmanship within the period and under the conditions described below.

This warranty covers parts and labor charges for repair or replacement of defective parts and begins on the date of purchase by the original retail purchaser. This warranty is transferable to another owner during the warranty period through a CFMOTO dealer, but any such transfer will not extend the original term of the warranty.

LIMITATIONS OF LIABILITY

THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIFTLOF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A ANY PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CAN NOT BE DISCLAIMED. THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTIES. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE **EXCLUDED** FROM COVERAGE UNDER THIS WARRANTY SOME STATES/PROVINCES DO NOT ALLOW FOR THE DISCLAIMERS. LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE. AS ARESULT. THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM STATE TO STATE, OR PROVINCE

TO PROVINCE.

Neither the distributor, CFMOTO dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the product, and other than those contained in this limited warranty, if made, shall not be enforceable against CFMOTO. CFMOTO reserves the right to modify this warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the products sold while this warranty is in effect.

REGISTRATION

The Dealer must register the vehicle online and provide the completed registration form to ZHEJIANG CFMOTO POWER CO., LTD within ten (10) days of completing the sale of the vehicle. Please note that NO warranty claims will be processed unless the product warranty online registration form is completed and the form is received by ZHEJIANG CFMOTO POWER CO., LTD from the Dealer. Initial dealer preparation and set-up of your vehicle is very important in ensuring trouble-free operation. Purchasing a machine in the crate or without proper dealer set-up will void your warranty coverage.

EXCLUSIONS-ARE NOT WARRANTED

The following are not warranted under any circumstances:

- 1. Normal wear and tear:
- 2. Damage caused by abuse, abnormal use, neglect or operation of the product in a -170-

manner inconsistent with the recommended operation described in the Owner's Manual;

- 3. Damage caused by failure to provide proper maintenance and/or storage, as described in the Owner's Manual;
- 4.Damage resulting from removal of parts, improper repairs, service, maintenance, or use of parts not manufactured or approved by CFMOTO or resulting from repairs done by a person that is not an authorized servicing CFMOTO dealer;
- 5. Routine maintenance items, tune-ups, adjustments;
- 6. Damage resulting from accident, submersion, fire, theft, vandalism or any force majeure;
- 7. Operation with fuels, oils or lubricants which are not suitable for use with the product (see the Owner's Manual);
- 8. Damages from rust, corrosion or exposure to the elements;
- 9. Damage resulting from water or snow ingestion;
- 10. Damage resulting from the racing or any other competitive activity
- 11. Damage resulting from use of vehicle as a rental vehicle.
- 12. Damage resulting from the vehicle has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use;
- 13. Incidental or consequential damages, or damages of any kind including without limitation towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan

payments, loss of time, loss of income etc.

WARRANTY COVERAGE PERIOD

This warranty will be in effect from the date of delivery to the first retail consumer. For the applicable period below:

Twelve (12) CONSECUTIVE MONTHS, for private use owners. Any vehicles used for commercial purposes will have their warranty period reduced to six (6) months.

This warranty period is the CFMOTO factory's basic warranty period, and the duration of this warranty may vary by international region based upon local laws, regulations and distributors' policy. Please Note the warranty period you get from dealers may the same or more than this limited warranty, but not less.

If ZHEJIANG CFMOTO POWER CO., LTD covers a full engine replacement or a complete vehicle replacement under this warranty, the warranty period does not get extended and remains the same as the original purchase date of the vehicle at issue.

LIMITATIONS OF WARRANTIES AND REMEDIES

The CFMOTO limited warranty excludes damages or failures caused by abuse, accident, fire, or any other cause other than a defect in materials or workmanship and provides no coverage for consumable components, general wear items, or any parts exposed to friction surfaces, stresses, environmental conditions and/or contamination for which they were not designed or not intended, including but not limited to the following items:

- Bushings
- Wheels and tires
- Suspension components
- Seat components
- Clutches and components
- Steering components
- Batteries
- Light bulbs/Sealed beam lamps
- Filter
- Lubricants

- Bearings
- Finished and unfinished surface
- Engine components
- Drive belts
- Hydraulic components and fluids
- Circuit breakers/Fuses
- Spark plugs
- Sealants
- Coolants
- Bearings

CONDITIONS TO HAVE WARRANTY COVERAGE

This warranty coverage is available only if each of the following conditions has been fulfilled:

- The CFMOTO ATV must be purchased as new and unused by its first owner from a CFMOTO dealer authorized to distribute CFMOTO ATV in the country in which the sale occurred;
- 2. The CFMOTO specified pre-delivery inspection process must be completed and documented and signed by the purchaser;
- 3. The **CFMOTO ATV** must have undergone proper registration by an authorized CFMOTO dealer;

- 4. The **CFMOTO ATV** must be purchased in the country in which the purchaser resides:
- 5. Routine maintenance outlined in the Owner's manual must be timely performed in order to maintain warranty coverage. CFMOTO reserves the right to make warranty coverage contingent upon proof of proper maintenance. CFMOTO will not honor this limited warranty to any private use owner or commercial use owner if one of the preceding conditions has not been met. Such limitations are necessary in order to allow CFMOTO to preserve both the safety of its products, and also that of its consumers and the general public.

HOW TO OBTAIN WARRANTY SERVICE

The customer must cease using the **CFMOTO ATV** upon the appearance of an anomaly. The customer must notify a servicing CFMOTO dealer within three (3) days of the appearance of a defect, and provide it with reasonable access to the product and reasonable opportunity to repair it. The customer must also present to the authorized CFMOTO dealer, proof of purchase of the product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair. All parts replaced under this limited warranty become the property of CFMOTO.

WHAT CFMOTO DEALER WILL DO

A CFMOTO authorized Dealer must perform warranty coverage repairs at no charge to the customer, even if they are not the dealer that sold the CFMOTO vehicle to the customer and must use CFMOTO OEM parts for all warranty repairs. All vehicles sold by the dealer must be inspected and tested by the dealer to ensure proper performance and operation prior to delivery to the customer. No vehicles may be delivered to a customer without first passing a dealer inspection and an operational test.

EXPORTED PRODUCTS

EXCEPT WHERE SPECIFICALLY REQUIRED BY LAW, THERE IS NO WARRANTY OR SERVICE BULLETIN COVERAGE ON THIS PRODUCT IF IT IS SOLD OUTSIDE THE COUNTRY OF THE SELLING DEALER'S AUTHORIZED LOCATION. This policy does not apply to products that have received authorization for export from CFMOTO. Dealers may not give authorization for export. You should consult an authorized dealer to determine this product's warranty or service coverage if you have any questions. This policy does not apply to products registered to government officials or military personnel on assignment outside the country of the selling dealer's authorized location. This policy does not apply to Safety Bulletins.



ZHEJIANG CFMOTO POWER CO., LTD.

No.116, Wuzhou Road, Yuhang Economic Development Zone, Hangzhou 311100, Zhejiang Province, China Tel: 86-571-86258863 Fax: +86-571-89265788 E-mail: service@cfmoto.com.cn http://global.cfmoto.com